

# Industrial communication solutions for Windows

## XAND4325 Driver Manual

### *AND AD-4325V Weight Indicator Protocol Driver*

#### Contents

XAND4325 technical specifications .....	2
General information.....	2
Command list .....	2
Read Configured Value .....	2
Read Final Net .....	3
Read Setpoint .....	3
Read Accessories .....	4
Set Zero .....	4
Set Tare .....	4
Toggle Display From Gross to Net Mode.....	4
Toggle Display From Net to Gross Mode.....	4
Write All Setpoint Parameters.....	5
Write Setpoint Parameters .....	5
Set Accessories .....	5
Change Code .....	6
Begin Batching.....	6
Halt Batching.....	6
Error messages .....	6
Supported devices.....	7

CPKSoft Engineering

Industrial communication drivers.

[www.cpksoft.com](http://www.cpksoft.com)

[www.facebook.com/cpksoftengineering](http://www.facebook.com/cpksoftengineering)

[cpksoftengineering@hotmail.com](mailto:cpksoftengineering@hotmail.com)

phone: 54-911-45788354

1990-2012

# Industrial communication solutions for Windows

## XAND4325 technical specifications

### General information

XAND4325 allows you to connect to the A&D COMPANY Ltd., AD-4325V weighing indicator scales.

#### CONFIGURATION:

*In order to configure parameters related to the scale communication, the following steps must be followed:*

- 1) Press STND\OPR. The display must be turned on.
- 2) Open the front panel cover where the Dip-Switch are.
- 3) Turn the Dip-Switch S3 ON. "Func" should be displayed and a "01" should blink on the setpoint display.
- 4) Using the keys "<", ">", "+" and "-" select the number of the function to be changed and hit "ENTER". A 0 should blink on the final weight display.
- 5) Use keys "+" and "-" to enter the desired value. Then hit "ENTER" to set the value.
- 6) Once the configuration is ready, change the Dip-Switch S3 to OFF. "END" should be displayed.

*The following are the functions to configure:*

- F41 - WXYZ combined parameter, where
- W = Indicates Baud Rate (2-1200 Bauds, 3-2400 Bauds, 4-4800 Bauds or 5-9600 Bauds)
  - X = Indicates data Bits and Stop Bits
  - 0 = 7 Data bits and 1 Stop bit
  - 1 = 7 Data bits and 2 Stop bit
  - 2 = 8 Data bits and 1 Stop bit
  - 3 = 8 Data bits and 2 Stop bit
  - Y = Indicates Parity (0-Even, 1-Odd or 2-No Parity)
  - Z = End of message (zero must be set, i.e. CR+LF)
- F42 - Output Data
- 1 = Sends the same displayed information
  - 2 = GROSS Data
  - 3 = NET Data
  - 4 = TARE Data
- F43 - Output Mode Must be set on option 5 (Command Mode #2)
- F44 - Output Availability Must be set on option 1 (Always available)
- F45 - Output Format Must be set on option 1 (Sending with SP Code Number)
- F46 - Communication Mode Must be set on option 2 (Sending with Address)
- F47 - Address Number A number from 0 to 9 may be set.

### Command list

#### Read Configured Value

##### **Description of this command:**

This command allows you to read the gross weight, net weight or tare according to the way the scale is configured in the function 'F42'

##### **Methods used to run this command:**

Analog Input

##### **Number of points accepted by this command:**

1-4

##### **Meaning of the DriverP0 parameter:**

Indicates the station address (0-9).

##### **Meaning of the DriverP1 parameter:**

0

##### **Values that are returned:**

Value in Point/Value (0) = Actual weight.

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/

cpksoftengineering

cpksoftengineering@

hotmail.com

phone: 54-911-45788354

1990-2012

# Industrial communication solutions for Windows

Value in PointValue (1) = Overload state.

- 0 = Overload.
- 1 = Stable overload.
- 2 = Unstable overload.

Value in PointValue (2) = Weight type.

- 0 = Net.
- 1 = Gross.
- 2 = Tare.

Value in PointValue (1) = Unit Indicator.

- 0 = Kilogram.
- 1 = Pound.
- 2 = Tonne.

## Read Final Net

### Description of this command:

This command allows you to read the final net weight.

### Methods used to run this command:

Analog Input

### Number of points accepted by this command:

1-4

### Meaning of the DriverP0 parameter:

Indicates the station address (0-9).

### Meaning of the DriverP1 parameter:

13

### Values that are returned:

Value in PointValue (0) = Actual weight.

Value in PointValue (1) = Overload state.

- 0 = Overload.
- 1 = Stable overload.
- 2 = Unstable overload.

Value in PointValue (2) = Weight type.

- 0 = Net.
- 1 = Gross.
- 2 = Tare.

Value in PointValue (1) = Unit Indicator.

- 0 = Kilogram.
- 1 = Pound.
- 2 = Tonne.

## Read Setpoint

### Description of this command:

Allows you to read the Final Weight, Free Fall, Preliminary Output, Over and Under Weight parameters.

### Methods used to run this command:

Analog Input

### Number of points accepted by this command:

1-5

### Meaning of the DriverP0 parameter:

Indicates the station address (0-9).

### Meaning of the DriverP1 parameter:

1

### Meaning of the DriverP2 parameter:

Indicates the Code Number (0-99).

### Values that are returned:

Value in PointValue (0) = Final Weight.

Value in PointValue (1) = Free Fall.

Value in PointValue (2) = Preliminary Output.

Value in PointValue (3) = Over Weight.

Value in PointValue (4) = Under Weight.

CPKSoft Engineering

Industrial communication  
drivers.

www.cpksoft.com

www.facebook.com/

cpksoftengineering

cpksoftengineering@

hotmail.com

phone: 54-911-45788354

1990-2012

# Industrial communication solutions for Windows

## Read Accessories

**Description of this command:**

Allows you to read the Optional Preliminary and Zero Band parameters.

**Methods used to run this command:**

Analog Input

**Number of points accepted by this command:**

1-2

**Meaning of the DriverP0 parameter:**

Indicates the station address (0-9).

**Meaning of the DriverP1 parameter:**

2

**Values that are returned:**

Value in PointValue (0) = Optional Preliminary.

Value in PointValue (1) = Zero Band.

## Set Zero

**Description of this command:**

This command sets the scale display to zero.

**Methods used to run this command:**

Digital Output

**Number of points accepted by this command:**

1

**Meaning of the DriverP0 parameter:**

Indicates the station address (0-9).

**Meaning of the DriverP1 parameter:**

3

## Set Tare

**Description of this command:**

This command displays the tare value on the scale and turns it to the NET mode.

**Methods used to run this command:**

Digital Output

**Number of points accepted by this command:**

1

**Meaning of the DriverP0 parameter:**

Indicates the station address (0-9).

**Meaning of the DriverP1 parameter:**

4

## Toggle Display From Gross to Net Mode

**Description of this command:**

Changes display from GROSS to NET mode.

**Methods used to run this command:**

Digital Output

**Number of points accepted by this command:**

1

**Meaning of the DriverP0 parameter:**

Indicates the station address (0-9).

**Meaning of the DriverP1 parameter:**

5

## Toggle Display From Net to Gross Mode

**Description of this command:**

Changes display from NET to GROSS mode.

**Methods used to run this command:**

Digital Output

**Number of points accepted by this command:**

1

CPKSoft Engineering

Industrial communication  
drivers.

[www.cpksoft.com](http://www.cpksoft.com)

[www.facebook.com/  
cpksoftengineering](http://www.facebook.com/cpksoftengineering)

[cpksoftengineering@  
hotmail.com](mailto:cpksoftengineering@hotmail.com)

phone: 54-911-45788354

1990-2012

# Industrial communication solutions for Windows

**Meaning of the DriverP0 parameter:**

Indicates the station address (0-9).

**Meaning of the DriverP1 parameter:**

6

## Write All Setpoint Parameters

**Description of this command:**

Allows you to set the Final Weight, Free Fall, Preliminary Output, Over, Under, Optional Preliminary and Zero Band parameters.

**Methods used to run this command:**

Analog Output

**Number of points accepted by this command:**

7

**Meaning of the DriverP0 parameter:**

Indicates the station address (0-9).

**Meaning of the DriverP1 parameter:**

7

**Values that are sent:**

Value in PointValue (0) = Final Weight.

Value in PointValue (1) = Free Fall.

Value in PointValue (2) = Preliminary Output.

Value in PointValue (3) = Over Weight.

Value in PointValue (4) = Under Weight.

Value in PointValue (5) = Optional Preliminary.

Value in PointValue (6) = Zero Band.

## Write Setpoint Parameters

**Description of this command:**

Allows you to set the Final Weight, Free Fall, Preliminary Output, Over and Under Weight parameters.

**Methods used to run this command:**

Analog Output

**Number of points accepted by this command:**

5

**Meaning of the DriverP0 parameter:**

Indicates the station address (0-9).

**Meaning of the DriverP1 parameter:**

8

**Meaning of the DriverP2 parameter:**

Indicates the Code Number (0-99).

**Values that are sent:**

Value in PointValue (0) = Final Weight.

Value in PointValue (1) = Free Fall.

Value in PointValue (2) = Preliminary Output.

Value in PointValue (3) = Over Weight.

Value in PointValue (4) = Under Weight.

## Set Accessories

**Description of this command:**

Allows you to set the Optional Preliminary and Zero Band parameters.

**Methods used to run this command:**

Analog Output

**Number of points accepted by this command:**

2

**Meaning of the DriverP0 parameter:**

Indicates the station address (0-9).

**Meaning of the DriverP1 parameter:**

9

**Values that are sent:**

Value in PointValue (0) = Optional Preliminary.

CPKSoft Engineering

Industrial communication drivers.

[www.cpksoft.com](http://www.cpksoft.com)

[www.facebook.com/cpksoftengineering](http://www.facebook.com/cpksoftengineering)

[cpksoftengineering@hotmail.com](mailto:cpksoftengineering@hotmail.com)

phone: 54-911-45788354

1990-2012

# Industrial communication solutions for Windows

Value in PointValue (1) = Zero Band.

## Change Code

**Description of this command:**

Allows you to set the Code Number.

**Methods used to run this command:**

Digital Output

**Number of points accepted by this command:**

1

**Meaning of the DriverP0 parameter:**

Indicates the station address (0-9).

**Meaning of the DriverP1 parameter:**

10

**Meaning of the DriverP2 parameter:**

Indicates the Code Number (0-99).

## Begin Batching

**Description of this command:**

Allows you to begin batching.

**Methods used to run this command:**

Digital Output

**Number of points accepted by this command:**

1

**Meaning of the DriverP0 parameter:**

Indicates the station address (0-9).

**Meaning of the DriverP1 parameter:**

11

## Halt Batching

**Description of this command:**

Allows you to halt batching.

**Methods used to run this command:**

Digital Output

**Number of points accepted by this command:**

1

**Meaning of the DriverP0 parameter:**

Indicates the station address (0-9).

**Meaning of the DriverP1 parameter:**

12

## Error messages

---

The following list shows the possible error messages that can be returned by the driver during a failed communication in the 'Status' property.

[1005] DRIVER (Internal): Invalid driver stage  
[1300] PROTOCOL (Timeout): No answer  
[1410] PROTOCOL (Format): Invalid device id in response  
[1426] PROTOCOL (Format): Returned code is other than sent  
[2117] CONFIG (NumValues): Invalid number of values (must be 2)  
[2127] CONFIG (NumValues): Invalid number of values (must be 5)  
[2130] CONFIG (NumValues): Invalid number of values (must be 7)  
[2194] CONFIG (NumValues): Too many values (max=2)  
[2216] CONFIG (NumValues): Too many values (max=4)  
[2223] CONFIG (NumValues): Too many values (max=5)  
[3017] CONFIG (P0): Invalid device address (0-9)  
[3508] CONFIG (P1): Invalid command  
[4028] CONFIG (P2): Invalid code number (0-99)  
[8190] CONFIG (Remote): Invalid command

CPKSoft Engineering

Industrial communication  
drivers.

www.cpksoft.com

www.facebook.com/

cpksoftengineering

cpksoftengineering@

hotmail.com

phone: 54-911-45788354

1990-2012

# Industrial communication solutions for Windows

## Supported devices

---

This driver can communicate with these devices, but is not necessarily limited to this list:

AND COMPANY Ltd. AD-4325V Weighing Indicator Scales  
WEIGHTECK AC-9200 Weighing Indicator

CPKSoft Engineering

Industrial communication drivers.

[www.cpksoft.com](http://www.cpksoft.com)

[www.facebook.com/cpksoftengineering](https://www.facebook.com/cpksoftengineering)

[cpksoftengineering@hotmail.com](mailto:cpksoftengineering@hotmail.com)

phone: 54-911-45788354

1990-2012