

Industrial communication solutions for Windows

XCEWE Driver Manual

Cewe Instruments Using IEC 1107 Data Protocol Driver

Contents

XCEWE technical specifications	4
General information.....	4
Command list	4
Get Historic Information.....	4
Read Meter Serial Number.....	6
Read Date.....	6
Read Time	7
Read if Alarm Active.....	7
Read Latest Alarm Reset	8
Read Number of Alarms Since Reset.....	8
Read Alarms Since Reset 1-25	9
Read Language.....	10
Read Predefined Id's, Primary Set.....	10
Read All Energy Import and Export	10
Read External Input Registers.....	11
Read Tariff Data Value 1.....	12
Read Tariff Data Value 2.....	12
Read Tariff Data Value 3.....	13
Read Tariff Data Value 4.....	13
Read Tariff Data Value 5.....	14
Read Average Demand Period.....	15
Read Last Reset of Billing Registers	15
Read Maximum Demand Values 1	16
Read Date and Time for Maximum Demands 1	16
Read Highest Demand Value 1	17
Read Date and Time for the Three Highest Demand 1	17
Read Average Value of Highest Demand 1	18
Read Maximum Demand Values 2	19
Read Date and Time for Maximum Demands 2	19
Read Highest Demand Value 2	20
Read Date and Time for the Three Highest Demand 2	20
Read Average Value of Highest Demand 2	21
Read Maximum Demand Values 3	22

CPKSoft Engineering

Industrial communication
drivers.

www.cpksoft.com

[www.facebook.com/
cpksoftengineering](http://www.facebook.com/cpksoftengineering)

[cpksoftengineering@
hotmail.com](mailto:cpksoftengineering@hotmail.com)

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Read Date and Time for Maximum Demands 3	22
Read Highest Demand Value 3	23
Read Date and Time for the Three Highest Demand 3	23
Read Average Value of Highest Demand 3	24
Read Current All Phases Primary Values	25
Read Line Voltage All Phases Primary Values	25
Read Phase Voltage All Phases Primary Values	26
Read Active Power All Phases Primary Values	26
Read Total Active Power Primary Value	27
Read Reactive Power All Phases Primary Values	27
Read Total Reactive Power Primary Value.....	28
Read Apparent Power All Phases Primary Values.....	28
Read Total Apparent Power Primary Value	29
Read Frequency.....	29
Read Power Factor All Phases.....	29
Read Total Power Factor.....	30
Read Time Controlled by 50 or 60 Hz.....	30
Read Start Summer Time Present Year and Start Winter Time Present Year.....	31
Read Fixed Holidays	32
Read Holidays Present Year	32
Read Holidays Year + 1	33
Read Holidays Year + 2	34
Read Holidays Year + 3	34
Read Holidays Year + 4	35
Read Holidays Year + 5	35
Read Holidays Year + 6	36
Read Start Date, Present Tariff	37
Read Energy Rates and Demand Rates, Present Tariff.....	37
Read Start Date, Comming Tariff.....	38
Read Energy Rates and Demand Rates, Comming Tariff.....	38
Read Solid State Relay 1 Config	39
Read Remote Control of Relay 1	39
Read Pulse Length Relay Output and End MD-Period.....	40
Read Voltage and Current Transformer Ratio.....	40
Write Date	41
Write Time.....	41
Write Language Used.....	42
Write Alarm Reset	42
Reset of MD	43
Write Logging Reset.....	43
Write Billing Reset.....	44
Write Time Controlled.....	44

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/cpksoftengineering

cpksoftengineering@hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Read Consecutive Registers	45
Write Consecutive Registers	46
ID Number Table for Read Commands.....	46
ID Number Table for Write Commands.....	49
Error messages	50
Supported devices.....	50

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/cpksoftengineering

cpksoftengineering@hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

XCEWE technical specifications

General information

XCEWE driver allows you to connect to any CEWE Instruments meter that communicates using data protocol IEC 1107 Mode C and uses any of the data formats supported. Its is recommended to send commands to the CEWE meter every 5 seconds minimum and this involves configuring the "HMITalk1.ScanStart" and "HMITalk1.ScanRate" properties to have small values. This driver is also capable of receiving available historic information from different meter devices and store this information in individual ASCII files.

Command list

Get Historic Information

Description of this command:

Reads the available historic information for a given number of channels in the meter's memory from a given start date and stores the samples in an ASCII file with a predefined format in the hard disk.

Meaning of the DriverP7 parameter:

Defines the root name for the .CEW configuration file containing special information required by the command, i.e. "C:\\HISTORIC\\DATA01.CEW".

Important note:

The format and contents of this file (.CEW) are explained at the end of this command.

Methods used to run this command:

Analog Input

1-6 (in fact, number of meter channels being read, plus one for the meter serial number)

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

2

Meaning of the DriverP2 parameter:

Indicates how many meter channels must be read from the meter (1-5). If left to 0, a value of 1 will be assumed.

Meaning of the DriverP3 parameter:

Indicates if the date specification must be detailed for each sample (0=NO, 1=YES). If 1 is selected, the file will contain 'full date information'.

Meaning of the DriverP4 parameter:

Indicates how many times the communication must be retried before abandoning it (usually set to 10 when using a modem). A communication is retried when any of these two errors appear:

- A checksum error is detected in the incoming message.
- The timeout period elapsed without receiving a reply.

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Meaning of the DriverP7 parameter:

Indicates the filename for the .CEW configuration file. For example: "C:\\HISTORIC\\CFGDATA.CEW". This filename will be used by default to store the .PRN log files only if the HMITalk1.DriverP8 is left empty.

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/

cpksoftengineering

cpksoftengineering@

hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

These values are read from the meter memory and indicate the factors to divide the meter channel values with before they are sent to the log-file. Can range from 0 to 32767.

Units1...5:

These texts are read from the meter memory and indicate the engineering units for the corresponding channels read.

The format used to give this information is similar to the one used in a typical Windows .INI file:

```
[[HistoricInfo] LogFile=C:\MYLOGS\CEWE0001.PRN Header="This will be my header"
LastDate=YYMMDD,hhmm SamplesInBlock=12 Decimals1=0 Decimals2=1
```

Example:

```
[[HistoricInfo] LogFile=C:\HISTORIC\CEWE0001.PRN Header="Time
", "TRNGR51P", "TRNGR51S" LastDate=950606,2015
```

(The rest of the fields can be omitted).

The format of the historic file generated is the following

(with date information as MM/DD/YY):

```
Header (Optional) "19/05/95 00:15",287,...,224 "00:30",289,...,229 "00:45",293,...,227
"01:00",296,...,225 "01:15",295,...,232 "01:30",268,...,229 "01:45",264,...,230 etc.
```

Read Meter Serial Number

Description of this command:

Reads the meter's serial number information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1

Meaning of the DriverP0 parameter:

0

Meaning of the DriverP1 parameter:

1

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

Value in PointValue (0) = The meter serial number whose memory was collected as a combined number of the form XYYYYYYY, where: XX = ASCII code of the first letter in the serial number. YYYYYYY = The remaining six numeric digits.

Read Date

Description of this command:

Reads the meter's date information formatted as YY/MM/DD.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-3

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

21

Meaning of the DriverP3 parameter:

10

Meaning of the DriverP4 parameter:

3

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/

cpksoftengineering

cpksoftengineering@

hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

Value in PointValue (0) = Year
Value in PointValue (1) = Month
Value in PointValue (2) = Day

Read Time

Description of this command:

Reads the meter's time information formatted as hh/mm/ss.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-3

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

22

Meaning of the DriverP3 parameter:

10

Meaning of the DriverP4 parameter:

3

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

Value in PointValue (0) = Hour
Value in PointValue (1) = Minutes
Value in PointValue (2) = Seconds

Read if Alarm Active

Description of this command:

Informs if there is an alarm active (1=Active, 0=No alarm).

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

31

Meaning of the DriverP3 parameter:

30

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/

cpksoftengineering

cpksoftengineering@

hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Meaning of the DriverP4 parameter:

1

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

Value in PointValue (0) = 1 if Active, 0 if No alarm.

Read Latest Alarm Reset

Description of this command:

Reads the latest alarm reset information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-6

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

32

Meaning of the DriverP3 parameter:

21

Meaning of the DriverP4 parameter:

6

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

Value in PointValue (0) = Number of resets

Value in PointValue (1) = Year

Value in PointValue (2) = Month

Value in PointValue (3) = Day

Value in PointValue (4) = Hour

Value in PointValue (5) = Minutes

Read Number of Alarms Since Reset

Description of this command:

Reads the number of alarms since reset information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

39

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/

cpksoftengineering

cpksoftengineering@

hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Meaning of the DriverP3 parameter:

1

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Read Alarms Since Reset 1-25

Description of this command:

Reads the alarms since reset 1-25 information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-175

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

40

Meaning of the DriverP3 parameter:

20

Meaning of the DriverP4 parameter:

7

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

Value in PointValue (0) = Number of resets of alarm since reset 1

Value in PointValue (1) = Year of alarm since reset 1

Value in PointValue (2) = Month of alarm since reset 1

Value in PointValue (3) = Day of alarm since reset 1

Value in PointValue (4) = Hour of alarm since reset 1

Value in PointValue (5) = Minutes of alarm since reset 1

Value in PointValue (6) = Seconds of alarm since reset 1

Value in PointValue (7) = Number of resets of alarm since reset 2

Value in PointValue (8) = Year of alarm since reset 2

Value in PointValue (9) = Month of alarm since reset 2

Value in PointValue (10) = Day of alarm since reset 2

Value in PointValue (11) = Hour of alarm since reset 2

Value in PointValue (12) = Minutes of alarm since reset 2

Value in PointValue (13) = Seconds of alarm since reset 2

...

Value in PointValue (168) = Number of resets of alarm since reset 25

Value in PointValue (169) = Year of alarm since reset 25

Value in PointValue (170) = Month of alarm since reset 25

Value in PointValue (171) = Day of alarm since reset 25

Value in PointValue (172) = Hour of alarm since reset 25

Value in PointValue (173) = Minutes of alarm since reset 25

Value in PointValue (174) = Seconds of alarm since reset 25

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/cpksoftengineering

[cpksoftengineering@](mailto:cpksoftengineering@hotmail.com)

[hotmail.com](mailto:cpksoftengineering@hotmail.com)

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Read Language

Description of this command:

Reads the language information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

70

Meaning of the DriverP3 parameter:

1

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Read Predefined Id's, Primary Set

Description of this command:

Reads the predefined Id's, primary set information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-9

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

80

Meaning of the DriverP3 parameter:

9

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Read All Energy Import and Export

Description of this command:

Reads the all energy import and export information.

Methods used to run this command:

Analog Input

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/

cpksoftengineering

cpksoftengineering@

hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Number of points accepted by this command:

1-6

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

101

Meaning of the DriverP3 parameter:

1

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

Value in PointValue (0) = Active energy import
Value in PointValue (1) = Active energy export
Value in PointValue (2) = Reactive energy import
Value in PointValue (3) = Reactive energy export
Value in PointValue (4) = Apparent energy import
Value in PointValue (5) = Apparent energy export

Read External Input Registers

Description of this command:

Reads the external input registers information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-3

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

107

Meaning of the DriverP3 parameter:

1

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

Value in PointValue (0) = External Input 1 Register
Value in PointValue (1) = External Input 2 Register
Value in PointValue (2) = External Input 3 Register

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/

cpksoftengineering

cpksoftengineering@

hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Read Tariff Data Value 1

Description of this command:

Reads the tariff data value 1.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-8

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

121

Meaning of the DriverP3 parameter:

1

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

- Value in PointValue (0) = Tariff data value 1-1
- Value in PointValue (1) = Tariff data value 1-2
- Value in PointValue (2) = Tariff data value 1-3
- Value in PointValue (3) = Tariff data value 1-4
- Value in PointValue (4) = Tariff data value 1-5
- Value in PointValue (5) = Tariff data value 1-6
- Value in PointValue (6) = Tariff data value 1-7
- Value in PointValue (7) = Tariff data value 1-8

Read Tariff Data Value 2

Description of this command:

Reads the tariff data value 2.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-8

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

131

Meaning of the DriverP3 parameter:

1

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/cpksoftengineering

cpksoftengineering@hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

Value in PointValue (0) = Tariff data value 2-1
Value in PointValue (1) = Tariff data value 2-2
Value in PointValue (2) = Tariff data value 2-3
Value in PointValue (3) = Tariff data value 2-4
Value in PointValue (4) = Tariff data value 2-5
Value in PointValue (5) = Tariff data value 2-6
Value in PointValue (6) = Tariff data value 2-7
Value in PointValue (7) = Tariff data value 2-8

Read Tariff Data Value 3

Description of this command:

Reads the tariff data value 3.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-8

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

141

Meaning of the DriverP3 parameter:

1

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

Value in PointValue (0) = Tariff data value 3-1
Value in PointValue (1) = Tariff data value 3-2
Value in PointValue (2) = Tariff data value 3-3
Value in PointValue (3) = Tariff data value 3-4
Value in PointValue (4) = Tariff data value 3-5
Value in PointValue (5) = Tariff data value 3-6
Value in PointValue (6) = Tariff data value 3-7
Value in PointValue (7) = Tariff data value 3-8

Read Tariff Data Value 4

Description of this command:

Reads the tariff data value 4.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-8

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/

cpksoftengineering

cpksoftengineering@

hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

151

Meaning of the DriverP3 parameter:

1

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

- Value in PointValue (0) = Tariff data value 4-1
- Value in PointValue (1) = Tariff data value 4-2
- Value in PointValue (2) = Tariff data value 4-3
- Value in PointValue (3) = Tariff data value 4-4
- Value in PointValue (4) = Tariff data value 4-5
- Value in PointValue (5) = Tariff data value 4-6
- Value in PointValue (6) = Tariff data value 4-7
- Value in PointValue (7) = Tariff data value 4-8

Read Tariff Data Value 5

Description of this command:

Reads the tariff data value 5.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-8

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

161

Meaning of the DriverP3 parameter:

1

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

- Value in PointValue (0) = Tariff data value 5-1
- Value in PointValue (1) = Tariff data value 5-2
- Value in PointValue (2) = Tariff data value 5-3
- Value in PointValue (3) = Tariff data value 5-4
- Value in PointValue (4) = Tariff data value 5-5
- Value in PointValue (5) = Tariff data value 5-6
- Value in PointValue (6) = Tariff data value 5-7
- Value in PointValue (7) = Tariff data value 5-8

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/

cpksoftengineering

cpksoftengineering@

hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Read Average Demand Period

Description of this command:

Reads the average demand period information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

170

Meaning of the DriverP3 parameter:

1

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Read Last Reset of Billing Registers

Description of this command:

Reads the last reset of billing registers information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-7

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

171

Meaning of the DriverP3 parameter:

20

Meaning of the DriverP4 parameter:

1

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

Value in PointValue (0) = Number of resets
Value in PointValue (1) = Year
Value in PointValue (2) = Month
Value in PointValue (3) = Day
Value in PointValue (4) = Hour
Value in PointValue (5) = Minutes
Value in PointValue (6) = Seconds

CPKSoft Engineering

Industrial communication
drivers.

www.cpksoft.com
www.facebook.com/
cpksoftengineering
cpksoftengineering@
hotmail.com
phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Read Maximum Demand Values 1

Description of this command:

Reads the maximum demand values 1 information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-5

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

180

Meaning of the DriverP3 parameter:

1

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

Value in PointValue (0) = Maximum demand values 1:1
Value in PointValue (1) = Maximum demand values 1:2
Value in PointValue (2) = Maximum demand values 1:3
Value in PointValue (3) = Maximum demand values 1:4
Value in PointValue (4) = Maximum demand values 1:5

Read Date and Time for Maximum Demands 1

Description of this command:

Reads the date and time for maximum demands 1 information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-30

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

185

Meaning of the DriverP3 parameter:

11

Meaning of the DriverP4 parameter:

6

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

Value in PointValue (0) = Year for maximum demand 1:1

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/cpksoftengineering

[cpksoftengineering@](mailto:cpksoftengineering@hotmail.com)

[hotmail.com](mailto:cpksoftengineering@hotmail.com)

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Value in PointValue (1) = Month for maximum demand 1:1
Value in PointValue (2) = Day for maximum demand 1:1
Value in PointValue (3) = Hour for maximum demand 1:1
Value in PointValue (4) = Minutes for maximum demand 1:1
Value in PointValue (5) = Seconds for maximum demand 1:1
Value in PointValue (6) = Year for maximum demand 1:2
Value in PointValue (7) = Month for maximum demand 1:2
Value in PointValue (8) = Day for maximum demand 1:2
Value in PointValue (9) = Hour for maximum demand 1:2
Value in PointValue (10) = Minutes for maximum demand 1:2
Value in PointValue (11) = Seconds for maximum demand 1:2
...
Value in PointValue (24) = Year for maximum demand 1:5
Value in PointValue (25) = Month for maximum demand 1:5
Value in PointValue (26) = Day for maximum demand 1:5
Value in PointValue (27) = Hour for maximum demand 1:5
Value in PointValue (28) = Minutes for maximum demand 1:5
Value in PointValue (29) = Seconds for maximum demand 1:5

Read Highest Demand Value 1

Description of this command:

Reads the highest demand value 1 information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-3

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

191

Meaning of the DriverP3 parameter:

1

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

Value in PointValue (0) = First highest demand value 1:1
Value in PointValue (1) = Second highest demand value 1:1
Value in PointValue (2) = Third highest demand value 1:1

Read Date and Time for the Three Highest Demand 1

Description of this command:

Reads the date and time for highest demand 1 information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-18

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/

cpksoftengineering

cpksoftengineering@

hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

195

Meaning of the DriverP3 parameter:

11

Meaning of the DriverP4 parameter:

6

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

- Value in PointValue (0) = Year for maximum demand 1:1
- Value in PointValue (1) = Month for maximum demand 1:1
- Value in PointValue (2) = Day for maximum demand 1:1
- Value in PointValue (3) = Hour for maximum demand 1:1
- Value in PointValue (4) = Minutes for maximum demand 1:1
- Value in PointValue (5) = Seconds for maximum demand 1:1
- Value in PointValue (6) = Year for maximum demand 1:2
- Value in PointValue (7) = Month for maximum demand 1:2
- Value in PointValue (8) = Day for maximum demand 1:2
- Value in PointValue (9) = Hour for maximum demand 1:2
- Value in PointValue (10) = Minutes for maximum demand 1:2
- Value in PointValue (11) = Seconds for maximum demand 1:2
- Value in PointValue (12) = Year for maximum demand 1:3
- Value in PointValue (13) = Month for maximum demand 1:3
- Value in PointValue (14) = Day for maximum demand 1:3
- Value in PointValue (15) = Hour for maximum demand 1:3
- Value in PointValue (16) = Minutes for maximum demand 1:3
- Value in PointValue (17) = Seconds for maximum demand 1:3

Read Average Value of Highest Demand 1

Description of this command:

Reads the average value of highest demand 1 information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

199

Meaning of the DriverP3 parameter:

1

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/

cpksoftengineering

cpksoftengineering@

hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Read Maximum Demand Values 2

Description of this command:

Reads the maximum demand values 2 information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-5

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

200

Meaning of the DriverP3 parameter:

1

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

Value in PointValue (0) = Maximum demand values 2:1
Value in PointValue (1) = Maximum demand values 2:2
Value in PointValue (2) = Maximum demand values 2:3
Value in PointValue (3) = Maximum demand values 2:4
Value in PointValue (4) = Maximum demand values 2:5

Read Date and Time for Maximum Demands 2

Description of this command:

Reads the date and time for maximum demands 2 information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-30

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

205

Meaning of the DriverP3 parameter:

11

Meaning of the DriverP4 parameter:

6

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

Value in PointValue (0) = Year for maximum demand 2:1

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/cpksoftengineering

[cpksoftengineering@](mailto:cpksoftengineering@hotmail.com)

[hotmail.com](mailto:cpksoftengineering@hotmail.com)

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Value in PointValue (1) = Month for maximum demand 2:1
Value in PointValue (2) = Day for maximum demand 2:1
Value in PointValue (3) = Hour for maximum demand 2:1
Value in PointValue (4) = Minutes for maximum demand 2:1
Value in PointValue (5) = Seconds for maximum demand 2:1
Value in PointValue (6) = Year for maximum demand 2:2
Value in PointValue (7) = Month for maximum demand 2:2
Value in PointValue (8) = Day for maximum demand 2:2
Value in PointValue (9) = Hour for maximum demand 2:2
Value in PointValue (10) = Minutes for maximum demand 2:2
Value in PointValue (11) = Seconds for maximum demand 2:2
...
Value in PointValue (24) = Year for maximum demand 2:5
Value in PointValue (25) = Month for maximum demand 2:5
Value in PointValue (26) = Day for maximum demand 2:5
Value in PointValue (27) = Hour for maximum demand 2:5
Value in PointValue (28) = Minutes for maximum demand 2:5
Value in PointValue (29) = Seconds for maximum demand 2:5

Read Highest Demand Value 2

Description of this command:

Reads the highest demand value 2 information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-3

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

211

Meaning of the DriverP3 parameter:

1

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

Value in PointValue (0) = First highest demand value 2:1
Value in PointValue (1) = Second highest demand value 2:1
Value in PointValue (2) = Third highest demand value 2:1

Read Date and Time for the Three Highest Demand 2

Description of this command:

Reads the date and time for highest demand 2 information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-18

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the

CPKSoft Engineering

Industrial communication
drivers.

www.cpksoft.com

www.facebook.com/

cpksoftengineering

cpksoftengineering@

hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

format yyxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

215

Meaning of the DriverP3 parameter:

11

Meaning of the DriverP4 parameter:

6

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

- Value in PointValue (0) = Year for maximum demand 2:1
- Value in PointValue (1) = Month for maximum demand 2:1
- Value in PointValue (2) = Day for maximum demand 2:1
- Value in PointValue (3) = Hour for maximum demand 2:1
- Value in PointValue (4) = Minutes for maximum demand 2:1
- Value in PointValue (5) = Seconds for maximum demand 2:1
- Value in PointValue (6) = Year for maximum demand 2:2
- Value in PointValue (7) = Month for maximum demand 2:2
- Value in PointValue (8) = Day for maximum demand 2:2
- Value in PointValue (9) = Hour for maximum demand 2:2
- Value in PointValue (10) = Minutes for maximum demand 2:2
- Value in PointValue (11) = Seconds for maximum demand 2:2
- Value in PointValue (12) = Year for maximum demand 2:3
- Value in PointValue (13) = Month for maximum demand 2:3
- Value in PointValue (14) = Day for maximum demand 2:3
- Value in PointValue (15) = Hour for maximum demand 2:3
- Value in PointValue (16) = Minutes for maximum demand 2:3
- Value in PointValue (17) = Seconds for maximum demand 2:3

Read Average Value of Highest Demand 2

Description of this command:

Reads the average value of highest demand 2 information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

219

Meaning of the DriverP3 parameter:

1

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/

cpksoftengineering

cpksoftengineering@

hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Read Maximum Demand Values 3

Description of this command:

Reads the maximum demand values 3 information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-5

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

220

Meaning of the DriverP3 parameter:

1

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

- Value in PointValue (0) = Maximum demand values 3:1
- Value in PointValue (1) = Maximum demand values 3:2
- Value in PointValue (2) = Maximum demand values 3:3
- Value in PointValue (3) = Maximum demand values 3:4
- Value in PointValue (4) = Maximum demand values 3:5

Read Date and Time for Maximum Demands 3

Description of this command:

Reads the date and time for maximum demands 3 information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-30

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0 HMITalk1. HMITalk1.DriverP2 = 225

Meaning of the DriverP3 parameter:

11

Meaning of the DriverP4 parameter:

6

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

- Value in PointValue (1) = Month for maximum demand 3:1
- Value in PointValue (2) = Day for maximum demand 3:1
- Value in PointValue (3) = Hour for maximum demand 3:1

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/cpksoftengineering

cpksoftengineering@hotmail.com

hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Value in PointValue (4) = Minutes for maximum demand 3:1
Value in PointValue (5) = Seconds for maximum demand 3:1
Value in PointValue (6) = Year for maximum demand 3:2
Value in PointValue (7) = Month for maximum demand 3:2
Value in PointValue (8) = Day for maximum demand 3:2
Value in PointValue (9) = Hour for maximum demand 3:2
Value in PointValue (10) = Minutes for maximum demand 3:2
Value in PointValue (11) = Seconds for maximum demand 3:2
...
Value in PointValue (24) = Year for maximum demand 3:5
Value in PointValue (25) = Month for maximum demand 3:5
Value in PointValue (26) = Day for maximum demand 3:5
Value in PointValue (27) = Hour for maximum demand 3:5
Value in PointValue (28) = Minutes for maximum demand 3:5
Value in PointValue (29) = Seconds for maximum demand 3:5

Read Highest Demand Value 3

Description of this command:

Reads the highest demand value 3 information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-3

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

231

Meaning of the DriverP3 parameter:

1

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

Value in PointValue (0) = First highest demand value 3:1
Value in PointValue (1) = Second highest demand value 3:1
Value in PointValue (2) = Third highest demand value 3:1

Read Date and Time for the Three Highest Demand 3

Description of this command:

Reads the date and time for highest demand 3 information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-18

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

CPKSoft Engineering

Industrial communication
drivers.

www.cpksoft.com

www.facebook.com/

cpksoftengineering

cpksoftengineering@

hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

235

Meaning of the DriverP3 parameter:

11

Meaning of the DriverP4 parameter:

6

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

- Value in PointValue (0) = Year for maximum demand 3:1
- Value in PointValue (1) = Month for maximum demand 3:1
- Value in PointValue (2) = Day for maximum demand 3:1
- Value in PointValue (3) = Hour for maximum demand 3:1
- Value in PointValue (4) = Minutes for maximum demand 3:1
- Value in PointValue (5) = Seconds for maximum demand 3:1
- Value in PointValue (6) = Year for maximum demand 3:2
- Value in PointValue (7) = Month for maximum demand 3:2
- Value in PointValue (8) = Day for maximum demand 3:2
- Value in PointValue (9) = Hour for maximum demand 3:2
- Value in PointValue (10) = Minutes for maximum demand 3:2
- Value in PointValue (11) = Seconds for maximum demand 3:2
- Value in PointValue (12) = Year for maximum demand 3:3
- Value in PointValue (13) = Month for maximum demand 3:3
- Value in PointValue (14) = Day for maximum demand 3:3
- Value in PointValue (15) = Hour for maximum demand 3:3
- Value in PointValue (16) = Minutes for maximum demand 3:3
- Value in PointValue (17) = Seconds for maximum demand 3:3

Read Average Value of Highest Demand 3

Description of this command:

Reads the average value of highest demand 3 information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

239

Meaning of the DriverP3 parameter:

1

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/

cpksoftengineering

cpksoftengineering@

hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Read Current All Phases Primary Values

Description of this command:

Reads the current all phases primary values information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-3

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

240

Meaning of the DriverP3 parameter:

3

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

Value in PointValue (0) = Current phase A primary value
Value in PointValue (1) = Current phase B primary value
Value in PointValue (2) = Current phase C primary value

Read Line Voltage All Phases Primary Values

Description of this command:

Reads the line voltage all phases primary values information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-3

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

241

Meaning of the DriverP3 parameter:

3

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

Value in PointValue (0) = Line voltage AN primary value
Value in PointValue (1) = Line voltage BN primary value
Value in PointValue (2) = Line voltage CN primary value

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/cpksoftengineering

cpksoftengineering@hotmail.com

cpksoftengineering@hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Read Phase Voltage All Phases Primary Values

Description of this command:

Reads the phase voltage all phases primary values information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-3

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

242

Meaning of the DriverP3 parameter:

3

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

Value in PointValue (0) = Phase voltage phase AB primary value
Value in PointValue (1) = Phase voltage phase BC primary value
Value in PointValue (2) = Phase voltage phase CA primary value

Read Active Power All Phases Primary Values

Description of this command:

Reads the active power all phases primary values information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-3

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

250

Meaning of the DriverP3 parameter:

3

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

Value in PointValue (0) = Active power phase A primary value
Value in PointValue (1) = Active power phase B primary value
Value in PointValue (2) = Active power phase C primary value

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/cpksoftengineering

cpksoftengineering@hotmail.com

hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Read Total Active Power Primary Value

Description of this command:

Reads the total active power primary value information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

251

Meaning of the DriverP3 parameter:

1

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Read Reactive Power All Phases Primary Values

Description of this command:

Reads the reactive power all phases primary values information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-3

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

252

Meaning of the DriverP3 parameter:

3

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

Value in PointValue (0) = Reactive power phase A primary value
Value in PointValue (1) = Reactive power phase B primary value
Value in PointValue (2) = Reactive power phase C primary value

CPKSoft Engineering

Industrial communication
drivers.

www.cpksoft.com
www.facebook.com/
cpksoftengineering
cpksoftengineering@
hotmail.com
phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Read Total Reactive Power Primary Value

Description of this command:

Reads the total reactive power primary value information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

253

Meaning of the DriverP3 parameter:

1

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Read Apparent Power All Phases Primary Values

Description of this command:

Reads the apparent power all phases primary values information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-3

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

254

Meaning of the DriverP3 parameter:

3

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

Value in PointValue (0) = Apparent power phase A primary value
Value in PointValue (1) = Apparent power phase B primary value
Value in PointValue (2) = Apparent power phase C primary value

CPKSoft Engineering

Industrial communication
drivers.

www.cpksoft.com
www.facebook.com/
cpksoftengineering
cpksoftengineering@
hotmail.com
phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Read Total Apparent Power Primary Value

Description of this command:

Reads the total apparent power primary value information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

255

Meaning of the DriverP3 parameter:

1

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Read Frequency

Description of this command:

Reads the frequency information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

260

Meaning of the DriverP3 parameter:

1

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Read Power Factor All Phases

Description of this command:

Reads the power factor all phases information.

Methods used to run this command:

Analog Input

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/

cpksoftengineering

cpksoftengineering@

hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Number of points accepted by this command:

1-3

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

270

Meaning of the DriverP3 parameter:

3

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

Value in PointValue (0) = Power factor phase A

Value in PointValue (1) = Power factor phase B

Value in PointValue (2) = Power factor phase C

Read Total Power Factor

Description of this command:

Reads the total power factor information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

271

Meaning of the DriverP3 parameter:

1

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Read Time Controlled by 50 or 60 Hz

Description of this command:

Reads the time controlled by 50 or 60 Hz information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/cpksoftengineering

[cpksoftengineering@](mailto:cpksoftengineering@hotmail.com)

[hotmail.com](mailto:cpksoftengineering@hotmail.com)

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

301

Meaning of the DriverP3 parameter:

1

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Read Start Summer Time Present Year and Start Winter Time Present Year

Description of this command:

Reads start summer time present year and start winter time present year information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-49

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

311

Meaning of the DriverP3 parameter:

13

Meaning of the DriverP4 parameter:

7

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

Value in PointValue (0) = Year for start summer time present year.
Value in PointValue (1) = Month for start summer time present year.
Value in PointValue (2) = Day for start summer time present year.
Value in PointValue (3) = Hour for start summer time present year.
Value in PointValue (4) = Month for start winter time present year.
Value in PointValue (5) = Day for start winter time present year.
Value in PointValue (6) = Hour for start winter time present year.
Value in PointValue (7) = Year for start summer time present year + 1.
Value in PointValue (8) = Month for start summer time present year + 1.
Value in PointValue (9) = Day for start summer time present year + 1.
Value in PointValue (10) = Hour for start summer time present year + 1.
Value in PointValue (11) = Month for start winter time present year + 1.
Value in PointValue (12) = Day for start winter time present year + 1.
Value in PointValue (13) = Hour for start winter time present year + 1.
...

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/

cpksoftengineering

cpksoftengineering@

hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Value in PointValue (42) = Year for start summer time present year + 6.
Value in PointValue (43) = Month for start summer time present year + 6.
Value in PointValue (44) = Day for start summer time present year + 6.
Value in PointValue (45) = Hour for start summer time present year + 6.
Value in PointValue (46) = Month for start winter time present year + 6.
Value in PointValue (47) = Day for start winter time present year + 6.
Value in PointValue (48) = Hour for start winter time present year + 6.

Read Fixed Holidays

Description of this command:

Reads fixed holidays information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-20

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

400

Meaning of the DriverP3 parameter:

10

Meaning of the DriverP4 parameter:

2

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

Value in PointValue (0) = Month for fixed holidays.
Value in PointValue (1) = Day for fixed holidays.
Value in PointValue (2) = Month for fixed holidays + 1.
Value in PointValue (3) = Day for fixed holidays + 1.
Value in PointValue (4) = Month for fixed holidays + 2.
Value in PointValue (5) = Day for fixed holidays + 2.
...
Value in PointValue (16) = Month for fixed holidays + 8.
Value in PointValue (17) = Day for fixed holidays + 8.
Value in PointValue (18) = Month for fixed holidays + 9.
Value in PointValue (19) = Day for fixed holidays + 9.

Read Holidays Present Year

Description of this command:

Reads holidays present year information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-30

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/cpksoftengineering

cpksoftengineering@hotmail.com

hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

410

Meaning of the DriverP3 parameter:

10

Meaning of the DriverP4 parameter:

3

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

- Value in PointValue (0) = Year for holidays present year.
- Value in PointValue (1) = Month for holidays present year.
- Value in PointValue (2) = Day for holidays present year.
- Value in PointValue (3) = Year for holidays present year.
- Value in PointValue (4) = Month for holidays present year + 1.
- Value in PointValue (5) = Day for holidays present year + 1.
- Value in PointValue (6) = Year for holidays present year.
- Value in PointValue (7) = Month for holidays present year + 2.
- Value in PointValue (8) = Day for holidays present year + 2.
- ...
- Value in PointValue (24) = Year for holidays present year.
- Value in PointValue (25) = Month for holidays present year + 8.
- Value in PointValue (26) = Day for holidays present year + 8.
- Value in PointValue (27) = Year for holidays present year.
- Value in PointValue (28) = Month for holidays present year + 9.
- Value in PointValue (29) = Day for holidays present year + 9.

Read Holidays Year + 1

Description of this command:

Reads holidays year + 1 information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-30

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

430

Meaning of the DriverP3 parameter:

10

Meaning of the DriverP4 parameter:

3

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

- Value in PointValue (0) = Year for holidays year + 1:1.
- Value in PointValue (1) = Month for holidays year + 1:1.
- Value in PointValue (2) = Day for holidays year + 1:1.

...

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/

cpksoftengineering

cpksoftengineering@

hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Value in PointValue (27) = Year for holidays year + 1:9.
Value in PointValue (28) = Month for holidays year + 1:9.
Value in PointValue (29) = Day for holidays year + 1:9.

Read Holidays Year + 2

Description of this command:

Reads holidays year + 2 information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-30

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

450

Meaning of the DriverP3 parameter:

10

Meaning of the DriverP4 parameter:

3

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

Value in PointValue (0) = Year for holidays year + 2:1.

Value in PointValue (1) = Month for holidays year + 2:1.

Value in PointValue (2) = Day for holidays year + 2:1.

...

Value in PointValue (27) = Year for holidays year + 2:9.

Value in PointValue (28) = Month for holidays year + 2:9.

Value in PointValue (29) = Day for holidays year + 2:9.

Read Holidays Year + 3

Description of this command:

Reads holidays year + 3 information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-30

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

470

Meaning of the DriverP3 parameter:

10

Meaning of the DriverP4 parameter:

3

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/

cpksoftengineering

cpksoftengineering@

hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

Value in PointValue (0) = Year for holidays year + 3:1.

Value in PointValue (1) = Month for holidays year + 3:1.

Value in PointValue (2) = Day for holidays year + 3:1.

...

Value in PointValue (27) = Year for holidays year + 3:9.

Value in PointValue (28) = Month for holidays year + 3:9.

Value in PointValue (29) = Day for holidays year + 3:9.

Read Holidays Year + 4

Description of this command:

Reads holidays year + 4 information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-30

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

490

Meaning of the DriverP3 parameter:

10

Meaning of the DriverP4 parameter:

3

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

Value in PointValue (0) = Year for holidays year + 4:1.

Value in PointValue (1) = Month for holidays year + 4:1.

Value in PointValue (2) = Day for holidays year + 4:1.

...

Value in PointValue (27) = Year for holidays year + 4:9.

Value in PointValue (28) = Month for holidays year + 4:9.

Value in PointValue (29) = Day for holidays year + 4:9.

Read Holidays Year + 5

Description of this command:

Reads holidays year + 5 information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-30

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/

cpksoftengineering

cpksoftengineering@

hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

format yyxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

510

Meaning of the DriverP3 parameter:

10

Meaning of the DriverP4 parameter:

3

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

Value in PointValue (0) = Year for holidays year + 5:1.

Value in PointValue (1) = Month for holidays year + 5:1.

Value in PointValue (2) = Day for holidays year + 5:1.

...

Value in PointValue (27) = Year for holidays year + 5:9.

Value in PointValue (28) = Month for holidays year + 5:9.

Value in PointValue (29) = Day for holidays year + 5:9.

Read Holidays Year + 6

Description of this command:

Reads holidays year + 6 information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-30

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

530

Meaning of the DriverP3 parameter:

10

Meaning of the DriverP4 parameter:

3

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

Value in PointValue (0) = Year for holidays year + 6:1.

Value in PointValue (1) = Month for holidays year + 6:1.

Value in PointValue (2) = Day for holidays year + 6:1.

...

Value in PointValue (27) = Year for holidays year + 6:9.

Value in PointValue (28) = Month for holidays year + 6:9.

Value in PointValue (29) = Day for holidays year + 6:9.

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/

cpksoftengineering

cpksoftengineering@

hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Read Start Date, Present Tariff

Description of this command:

Reads start date, present tariff information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-3

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

600

Meaning of the DriverP3 parameter:

10

Meaning of the DriverP4 parameter:

3

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

Value in PointValue (0) = Year for start date, present tariff.
Value in PointValue (1) = Month for start date, present tariff.
Value in PointValue (2) = Day for start date, present tariff.

Read Energy Rates and Demand Rates, Present Tariff

Description of this command:

Reads energy rates and demand rates, present tariff information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-16

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

606

Meaning of the DriverP3 parameter:

8

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

Value in PointValue (0) = Energy rate 1 present tariff.
Value in PointValue (1) = Energy rate 2 present tariff.

...

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/cpksoftengineering

cpksoftengineering@hotmail.com

hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Value in PointValue (7) = Energy rate 8 present tariff.
Value in PointValue (8) = Demand rate 1 present tariff.
Value in PointValue (9) = Demand rate 2 present tariff.
...
Value in PointValue (17) = Demand rate 8 present tariff.

Read Start Date, Comming Tariff

Description of this command:

Reads start date, comming tariff information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-3

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

701

Meaning of the DriverP3 parameter:

10

Meaning of the DriverP4 parameter:

3

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

Value in PointValue (0) = Year for start date, comming tariff.
Value in PointValue (1) = Month for start date, comming tariff.
Value in PointValue (2) = Day for start date, comming tariff.

Read Energy Rates and Demand Rates, Comming Tariff

Description of this command:

Reads energy rates and demand rates, comming tariff information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-16

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

706

Meaning of the DriverP3 parameter:

8

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/cpksoftengineering

cpksoftengineering@hotmail.com

cpksoftengineering@hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

Value in PointValue (0) = Energy rate 1 coming tariff.
Value in PointValue (1) = Energy rate 2 coming tariff.

...

Value in PointValue (7) = Energy rate 8 coming tariff.
Value in PointValue (8) = Demand rate 1 coming tariff.
Value in PointValue (9) = Demand rate 2 coming tariff.

...

Value in PointValue (17) = Demand rate 8 coming tariff.

Read Solid State Relay 1 Config

Description of this command:

Reads solid state relay 1 config information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-18

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

801

Meaning of the DriverP3 parameter:

40

Meaning of the DriverP4 parameter:

3

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

Value in PointValue (0) = Type relay 1.
Value in PointValue (1) = State relay 1.
Value in PointValue (2) = Pulse constant relay 1.

...

Value in PointValue (15) = Type relay 6.
Value in PointValue (16) = State relay 6.
Value in PointValue (17) = Pulse constant relay 6.

Read Remote Control of Relay 1

Description of this command:

Reads remote control of relay 1 information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-6

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

CPKSoft Engineering

Industrial communication
drivers.

www.cpksoft.com

www.facebook.com/

cpksoftengineering

cpksoftengineering@

hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

811

Meaning of the DriverP3 parameter:

1

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

- Value in PointValue (0) = Remote control of relay 1.
- Value in PointValue (1) = Remote control of relay 2.
- Value in PointValue (2) = Remote control of relay 3.
- Value in PointValue (3) = Remote control of relay 4.
- Value in PointValue (4) = Remote control of relay 5.
- Value in PointValue (5) = Remote control of relay 6.

Read Pulse Length Relay Output and End MD-Period

Description of this command:

Reads pulse length relay output and end MD-period information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-2

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

820

Meaning of the DriverP3 parameter:

1

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

- Value in PointValue (0) = Pulse length relay output.
- Value in PointValue (1) = Pulse length end MD-period.

Read Voltage and Current Transformer Ratio

Description of this command:

Reads voltage and current transformer ratio information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-4

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/

cpksoftengineering

cpksoftengineering@

hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

number is indicated in the sign-on message. It can be additionally entered as a number with the format yxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

890

Meaning of the DriverP3 parameter:

2

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are returned:

Value in PointValue (0) = Voltage transformer ratio primary.
Value in PointValue (1) = Voltage transformer ratio secondary.
Value in PointValue (2) = Current transformer ratio primary.
Value in PointValue (3) = Current transformer ratio secondary.

Write Date

Description of this command:

Writes the meter's date information formatted as YY/MM/DD.

Methods used to run this command:

Analog Output

Number of points accepted by this command:

3

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

21

Meaning of the DriverP3 parameter:

2

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are sent:

Value in PointValue (0) = Year
Value in PointValue (1) = Month
Value in PointValue (2) = Day

Write Time

Description of this command:

Writes the meter's time information formatted as hh/mm/ss.

Methods used to run this command:

Analog Output

Number of points accepted by this command:

3

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/

cpksoftengineering

cpksoftengineering@

hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

number is indicated in the sign-on message. It can be additionally entered as a number with the format yxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

22

Meaning of the DriverP3 parameter:

2

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Values that are sent:

Value in PointValue (0) = Hour
Value in PointValue (1) = Minutes
Value in PointValue (2) = Seconds

Write Language Used

Description of this command:

Writes the language used (1=english, 2=swedish).

Methods used to run this command:

Analog Output

Number of points accepted by this command:

1

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

70

Meaning of the DriverP3 parameter:

0

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP5 parameter:

2

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Write Alarm Reset

Description of this command:

Writes the latest alarm reset information.

Methods used to run this command:

Analog Output

Number of points accepted by this command:

1

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/

cpksoftengineering

cpksoftengineering@

hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

73

Meaning of the DriverP3 parameter:

0

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP5 parameter:

1

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Reset of MD

Description of this command:

Reset of MD information.

Methods used to run this command:

Analog Output

Number of points accepted by this command:

1

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

76

Meaning of the DriverP3 parameter:

0

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP5 parameter:

1

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Write Logging Reset

Description of this command:

Writes logging reset.

Methods used to run this command:

Analog Output

Number of points accepted by this command:

1

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/

cpksoftengineering

cpksoftengineering@

hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Meaning of the DriverP2 parameter:

77

Meaning of the DriverP3 parameter:

0

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP5 parameter:

1

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Write Billing Reset

Description of this command:

Writes billing reset information.

Methods used to run this command:

Analog Output

Number of points accepted by this command:

1

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

172

Meaning of the DriverP3 parameter:

0

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP5 parameter:

1

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Write Time Controlled

Description of this command:

Writes time controlled information. 00 = Crystal controlled

- 50 = 50 Hertz
- 60 = 60 Hertz

Methods used to run this command:

Analog Output

Number of points accepted by this command:

1

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/

cpksoftengineering

cpksoftengineering@

hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Meaning of the DriverP2 parameter:

301

Meaning of the DriverP3 parameter:

0

Meaning of the DriverP4 parameter:

0

Meaning of the DriverP5 parameter:

2

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Read Consecutive Registers

Description of this command:

Before describing the command, it is important to note here that each register being read can return more than one value so the total number of values read is not necessarily the same number of registers read. This command can read HMITalk1.DriverNumPoints values coming from one or several consecutive registers. The driver will automatically decide (based on the current register format) how many registers must be requested to fill the HMITalk1.DriverNumPoints values reserved. Each register is identified by a unique ID number and uses a different format for returning the values it holds. To allow the driver interpret this data correctly, the format used by the registers must be the same and it is specified by using the HMITalk1.DriverP3 parameter reserved for this purpose (registers that use different formats cannot be read consecutively).

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-250

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

0

Meaning of the DriverP2 parameter:

Starting register ID Number (0-16383). See ID number table.

Meaning of the DriverP3 parameter:

Identifies the data format used by all the registers to be read:

- 1 = One decimal or float number (x.x).
- 2 = Two decimal or float numbers (x.x, x.x).
- 3 = Three decimal or float numbers (x.x, x.x, x.x).
- 4 = Four decimal or float numbers.
- 5 = Five decimal or float numbers.
- 6 = Six decimal or float numbers.
- 7 = Seven decimal or float numbers.
- 8 = Eight decimal or float numbers.
- 9 = Nine decimal or float numbers.
- 10 = Date or time type format (YYMMDD) or (hhmmss).
- 11 = Two consecutive date or time formats (YYMMDD,hhmmss).
- 12 = A date format and a reduced time format (YYMMDD,hhmm).
- 13 = Special date and time format (YYMMDDhh,MMDDhh).
- 15 = Fifteen decimal or float numbers.
- 20 = One decimal or float data and two date or time formats (x.x,YYMMDD,hhmmss).
- 21 = One decimal or float data, a date format and a reduced time format (x.x,YYMMDD,hhmm).
- 30 = A Y/N indication (Y returned as 1 and N as 0).
- 40 = Data of the following format: ST,B,XXXXX,TT

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/

cpksoftengineering

cpksoftengineering@

hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Values that are sent:

ST = 1 - Active import ST = 2 - Active export ST = 3 - Reactive import ST = 4 - Reactive export
 ST = 5 - Apparent import ST = 6 - Apparent export ST = 7 - Sum 1 ST = 8 - Sum 2 ST = 9 -
 Alarm 1 ST = 10 - Alarm 2 ST = 11 - End MD-period ST = 12 - Tariff control ST = 13 - Idle ST = 14
 - Remote control B = 0 - Open B = 1 - Close XXXX = Decimal or float number

Meaning of the DriverP4 parameter:

Indicates the maximum number of values read from each register. If 0, means that all the available values in each register must be read. If not 0, this number indicates that after reading HMITalk1.DriverP3 values, a new register must be requested to fill the next HMITalk1.DriverP3 values. This is done until HMITalk1.DriverNumPoints values are filled.

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

Write Consecutive Registers

Description of this command:

Writes the value/s of a one ID number. Before describing the command, it is important to note here that each register being written can consist of more than one value so the total number of values written is not necessarily the same number of registers affected. This command can write HMITalk1.DriverNumPoints values to one register. Each register is identified by a unique ID number and uses a different format for interpreting the values it receives.

Methods used to run this command:

Analog Output

Number of points accepted by this command:

1-125

Meaning of the DriverP0 parameter:

Identifies the meter serial number. It is assumed that serial numbers have the Cxxxxxx format, where xxxxxx is the numeric information supplied by this parameter. If 0, means that no serial number is indicated in the sign-on message. It can be additionally entered as a number with the format yyxxxxxx where: yy = ASCII code of the first letter in the serial number. xxxxxx = The remaining six numeric digits.

Meaning of the DriverP1 parameter:

3

Meaning of the DriverP2 parameter:

Starting register ID Number (0-16383). See ID number table.

Meaning of the DriverP3 parameter:

Identifies the data format used by all the registers to be written:

- 0 = decimal or float number (x.x).
- 1 = A reduced time format (hhmm).
- 2 = Date or time type format (YYMMDD) or (hhmmss).
- 3 = A Y/N indication (Y if is 1 and N is 0).

Meaning of the DriverP4 parameter:

Number of decimal digits used when float numbers are written (0-4).

Meaning of the DriverP5 parameter:

Number of integer digits used when numbers are written.

Meaning of the DriverP6 parameter:

This text parameter is used to define whether you are communicating via RS-232 or via the opto port with the Cewe device.

- Leave empty to communicate via RS-232.
- Type the word 'OPTO' to communicate via the opto port.

ID Number Table for Read Commands

ID No.	Description	Format	Reg.Size			
0020	Present tariff info	3 0 0021	Date	10	3	
0022	Time	10 3 0031	Alarm active	30	1	
0032	Latest alarm reset	21 6 0039	No. of alarms since reset			
1 0 0040	Alarm since reset 1	21	6 0041	Alarm since reset 2		
21 6 0042	Alarm since reset 3	21	6 0043	Alarm since reset 4		
21 6 0044	Alarm since reset 5	21	6 0045	Alarm since reset 6		

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com
 www.facebook.com/
 cpksoftengineering
 cpksoftengineering@
 hotmail.com
 phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

21	6 0046	Alarm since reset 7	21	6 0047	Alarm since reset 8
21	6 0048	Alarm since reset 9	21	6 0049	Alarm since reset 10
21	6 0050	Alarm since reset 11	21	6 0051	Alarm since reset 12
21	6 0052	Alarm since reset 13	21	6 0053	Alarm since reset 14
21	6 0054	Alarm since reset 15	21	6 0055	Alarm since reset 16
21	6 0056	Alarm since reset 17	21	6 0057	Alarm since reset 18
21	6 0058	Alarm since reset 19	21	6 0059	Alarm since reset 20
21	6 0060	Alarm since reset 21	21	6 0061	Alarm since reset 22
21	6 0062	Alarm since reset 23	21	6 0063	Alarm since reset 24
21	6 0064	Alarm since reset 25	21	6 0070	Language
1	0 0080	Predefined Id's, primary set	9	0 0101	Active energy, import
1	0 0102	Active energy, export	1	0 0103	Reactive energy, import
1	0 0104	Reactive energy, export	1	0 0105	Apparent energy, import
1	0 0106	Apparent energy, export	1	0 0107	External input 1 register
1	0 0108	External input 2 register	1	0 0109	External input 3 register
1	0 0121	Tariff data, value 1	1	0 0122	Tariff data, value 1
1	0 0123	Tariff data, value 1	1	0 0124	Tariff data, value 1
1	0 0125	Tariff data, value 1	1	0 0126	Tariff data, value 1
1	0 0127	Tariff data, value 1	1	0 0128	Tariff data, value 1
1	0 0131	Tariff data, value 2	1	0 0132	Tariff data, value 2
1	0 0133	Tariff data, value 2	1	0 0134	Tariff data, value 2
1	0 0135	Tariff data, value 2	1	0 0136	Tariff data, value 2
1	0 0137	Tariff data, value 2	1	0 0138	Tariff data, value 2
1	0 0141	Tariff data, value 3	1	0 0142	Tariff data, value 3
1	0 0143	Tariff data, value 3	1	0 0144	Tariff data, value 3
1	0 0145	Tariff data, value 3	1	0 0146	Tariff data, value 3
1	0 0147	Tariff data, value 3	1	0 0148	Tariff data, value 3
1	0 0151	Tariff data, value 4	1	0 0152	Tariff data, value 4
1	0 0153	Tariff data, value 4	1	0 0154	Tariff data, value 4
1	0 0155	Tariff data, value 4	1	0 0156	Tariff data, value 4
1	0 0157	Tariff data, value 4	1	0 0158	Tariff data, value 4
1	0 0161	Tariff data, value 5	1	0 0162	Tariff data, value 5
1	0 0163	Tariff data, value 5	1	0 0164	Tariff data, value 5
1	0 0165	Tariff data, value 5	1	0 0166	Tariff data, value 5
1	0 0167	Tariff data, value 5	1	0 0168	Tariff data, value 5
1	0 0170	Average demand period (minutes)	1	0 0171	Last reset of billing registers
20	7 0180	Maximun demand value 1:1	1	0 0181	Maximun demand value 1:2
1	0 0182	Maximun demand value 1:3	1	0 0183	Maximun demand value 1:4
1	0 0184	Maximun demand value 1:5	1	0 0185	Date,Time for maximun demand 1:1
11	6 0186	Date,Time for maximun demand 1:2	11	6 0187	Date,Time for maximun demand 1:3
11	6 0188	Date,Time for maximun demand 1:4	11	6 0189	Date,Time for maximun demand 1:5
11	6 0191	The highest demand values.	1	0	Demand value 1:1 0192
1	0	The second highest demand values.	1	0	Demand value 1:1 0193
1	0	The third highest demand values.	1	0	Demand value 1:1 0195
11	18	demands. 0199	11	18	demands. 0199
1	0 0200	Average value of 0191-0193	1	0 0201	Maximun demand value 2:1
1	0 0202	Maximun demand value 2:2	1	0 0203	Maximun demand value 2:3
1	0 0204	Maximun demand value 2:4	1	0 0205	Maximun demand value 2:5
11	6 0206	Date, time for maximun demand 2:1	11	6 0207	Date, time for maximun demand 2:2
11	6 0208	Date, time for maximun demand 2:3	11	6 0209	Date, time for maximun demand 2:4
11	6 0211	Date, time for maximun demand 2:5	11	6 0212	The highest demand values.
1	0	Demand value 1:1 0213	1	0	Demand value 1:1 0215
1	0	The second highest demand values.	1	0	The third highest demand values.
11	18	demands. 0219	11	18	demands. 0219
1	0 0220	Average value of 0211-0215	1	0 0221	Maximun demand value 2:1
1	0 0222	Maximun demand value 2:2	1	0 0223	Maximun demand value 2:3
1	0 0224	Maximun demand value 2:4	1	0 0225	Maximun demand value 2:5
11	6 0226	Date, time for maximun demand 2:1	11	6 0227	Date, time for maximun demand 2:2
11	6 0228	Date, time for maximun demand 2:3	11	6 0229	Date, time for maximun demand 2:4
11	6 0231	Date, time for maximun demand 2:5	11	6 0231	The highest

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/cpksoftengineering

cpksoftengineering@hotmail.com

hotmail.com

phone: 54-911-45788354

Industrial communication solutions for Windows

demand values. 1 0 Demand value 1:1 0232 The second highest demand values. 1 0 Demand value 1:1 0233 The third highest demand values. 1 0 Demand value 1:1 0235 Date, time for the three highest 11 18 demands. 0239 Average value of 0231-0233 1 0 0240 Current, all phases, primary values 3 0 0241 Line voltage, all phases, primary 3 0 values 0242 Phase voltage, all phases, primary 3 0 values 0250 Active power, all phases, primary values 3 0 0251 Total active power primary 3 0 0252 Reactive power, all phases, primary 3 0 values 0253 Total reactive power primary 3 0 0254 Apparent power, all phases, primary 3 0 values 0255 Total apparent power primary 3 0 0260 Frequency 1 0 0270 Power factor, all phases 3 0 0271 Total power factor 1 0 0301 Time controlled by 50 or 60 Hz 1 0 0311 Start summer time present year, 13 7 start winter time present year 0312 Start summer time present year + 1, 13 7 start winter time present year + 1 0313 Start summer time present year + 2, 13 7 start winter time present year + 2 0314 Start summer time present year + 3, 13 7 start winter time present year + 3 0315 Start summer time present year + 4, 13 7 start winter time present year + 4 0316 Start summer time present year + 5, 13 7 start winter time present year + 5 0317 Start summer time present year + 6, 13 7 start winter time present year + 6 0400 Fixed Holidays 1 10 2 0401 Fixed Holidays 2 10 2 0402 Fixed Holidays 3 10 2 0403 Fixed Holidays 4 10 2 0404 Fixed Holidays 5 10 2 0405 Fixed Holidays 6 10 2 0406 Fixed Holidays 7 10 2 0407 Fixed Holidays 8 10 2 0408 Fixed Holidays 9 10 2 0409 Fixed Holidays 10 10 2 0410 Holidays 1 present year 10 3 0411 Holidays 2 present year 10 3 0412 Holidays 3 present year 10 3 0413 Holidays 4 present year 10 3 0414 Holidays 5 present year 10 3 0415 Holidays 6 present year 10 3 0416 Holidays 7 present year 10 3 0417 Holidays 8 present year 10 3 0418 Holidays 9 present year 10 3 0419 Holidays 10 present year 10 3 0430 Holidays year 1:1 10 3 0431 Holidays year 1:2 10 3 0432 Holidays year 1:3 10 3 0433 Holidays year 1:4 10 3 0434 Holidays year 1:5 10 3 0435 Holidays year 1:6 10 3 0436 Holidays year 1:7 10 3 0437 Holidays year 1:8 10 3 0438 Holidays year 1:9 10 3 0439 Holidays year 1:10 10 3 0450 Holidays year 2:1 10 3 0451 Holidays year 2:2 10 3 0452 Holidays year 2:3 10 3 0453 Holidays year 2:4 10 3 0454 Holidays year 2:5 10 3 0455 Holidays year 2:6 10 3 0456 Holidays year 2:7 10 3 0457 Holidays year 2:8 10 3 0458 Holidays year 2:9 10 3 0459 Holidays year 2:10 10 3 0470 Holidays year 3:1 10 3 0471 Holidays year 3:2 10 3 0472 Holidays year 3:3 10 3 0473 Holidays year 3:4 10 3 0474 Holidays year 3:5 10 3 0475 Holidays year 3:6 10 3 0476 Holidays year 3:7 10 3 0477 Holidays year 3:8 10 3 0478 Holidays year 3:9 10 3 0479 Holidays year 3:10 10 3 0490 Holidays year 4:1 10 3 0491 Holidays year 4:2 10 3 0492 Holidays year 4:3 10 3 0493 Holidays year 4:4 10 3 0494 Holidays year 4:5 10 3 0495 Holidays year 4:6 10 3 0496 Holidays year 4:7 10 3 0497 Holidays year 4:8 10 3 0498 Holidays year 4:9 10 3 0499 Holidays year 4:10 10 3 0510 Holidays year 5:1 10 3 0511 Holidays year 5:2 10 3 0512 Holidays year 5:3 10 3 0513 Holidays year 5:4 10 3 0514 Holidays year 5:5 10 3 0515 Holidays year 5:6 10 3 0516 Holidays year 5:7 10 3 0517 Holidays year 5:8 10 3 0518 Holidays year 5:9 10 3 0519 Holidays year 5:10 10 3 0530 Holidays year 6:1 10 3 0531 Holidays year 6:2 10 3 0532 Holidays year 6:3 10 3 0533 Holidays year 6:4 10 3 0534 Holidays year 6:5 10 3 0535 Holidays year 6:6 10 3 0536 Holidays year 6:7 10 3 0537 Holidays year 6:8 10 3 0538 Holidays year 6:9 10 3 0539 Holidays year 6:10 10 3 0600 Start date, present tariff 10 3 0601 Season 1, present tariff 10 2 0602 Season 2, present tariff 10 2 0603 Season 3, present tariff 10 2 0604 Season 4, present tariff 10 2 0605 Season 5, present tariff 10 2 0606 Energy rates, present

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/

cpksoftengineering

cpksoftengineering@

hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

```

tariff      8  0 0607      Demand rates, present tariff      8  0 0610      Daytype A,
present tariff      10  2 0620      Daytype B, present tariff      10  2 0630
Daytype C, present tariff      10  2 0640      Daytype D, present tariff      10  2
0650      Daytype E, present tariff      10  2 0660      Daytype F, present tariff
10  2 0670      Daytype G, present tariff      10  2 0680      Daytype H, present tariff
10  2 0700      Start date, comming tariff      10  3 0701      Season 1, comming tariff
10  2 0702      Season 2, comming tariff      10  2 0703      Season 3, comming
tariff      10  2 0704      Season 4, comming tariff      10  2 0705      Season
5, comming tariff      10  2 0706      Energy rates, comming tariff      8  0 0707
Demand rates, comming tariff      8  0 0710      Daytype A, comming tariff      10
2 0720      Daytype B, comming tariff      10  2 0730      Daytype C, comming tariff
10  2 0740      Daytype D, comming tariff      10  2 0750      Daytype E, comming
tariff      10  2 0760      Daytype F, comming tariff      10  2 0770      Daytype
G, comming tariff      10  2 0780      Daytype H, comming tariff      10  2 0801
Solid state relay 1 config      40  3 0802      Solid state relay 2 config      40  3
0803      Solid state relay 3 config      40  3 0804      Solid state relay 4 config
40  3 0805      Solid state relay 5 config      40  3 0806      Solid state relay 6 config
40  3 0811      Remote control of relay 1      1  0 0812      Remote control of relay
2      1  0 0813      Remote control of relay 3      1  0 0814      Remote
control of relay 4      1  0 0815      Remote control of relay 5      1  0 0816
Remote control of relay 6      1  0 0820      Pulse length relay output      1  0
0821      Pulse length end MD-period      1  0 0851      Average demand 1:1 config
8  0 0852      Average demand 2:1 config      8  0 0853      Average demand 3:1
config      8  0 0854      Average demand 4:1 config      8  0 0855
Average demand 5:1 config      8  0 0856      Average demand 1:2 config      8
0 0857      Average demand 2:2 config      8  0 0858      Average demand 3:2 config
8  0 0859      Average demand 4:2 config      8  0 0860      Average demand 5:2
config      8  0 0861      Average demand 1:3 config      8  0 0862
Average demand 2:3 config      8  0 0863      Average demand 3:3 config      8
0 0864      Average demand 4:3 config      8  0 0865      Average demand 5:3 config
8  0
    
```

ID Number Table for Write Commands

ID No.	Description	Format	Reg.	Size	Int
0021	Date	2 3	0022	Time	2 3
0070	Language	0 1	2 0073	Alarm reset	
0 1	1 0076	Reset of MD	0 1	1 0077	Logging reset
0 1	1 0172	Billing reset	0 1	1 0301	Time controlled by
50 or 60 Hz	0 1	2 0400	Fixed Holidays 1	1	2 0401
Fixed Holidays 2	1	2 0402	Fixed Holidays 3	1	2 0403
Fixed Holidays 4	1	2 0404	Fixed Holidays 5	1	2 0405
Fixed Holidays 6	1	2 0406	Fixed Holidays 7	1	2 0407
Fixed Holidays 8	1	2 0408	Fixed Holidays 9	1	2 0409
Fixed Holidays 10	1	2 0410	Holidays 1 present year	2	3
0411	Holidays 2 present year	2	3 0412	Holidays 3 present year	
2 3 0413	Holidays 4 present year	2	3 0414	Holidays 5 present year	
2 3 0415	Holidays 6 present year	2	3 0416	Holidays 7 present year	
2 3 0417	Holidays 8 present year	2	3 0418	Holidays 9 present year	
2 3 0419	Holidays 10 present year	2	3 0430	Holidays year 1:1	
2 3 0431	Holidays year 1:2	2	3 0432	Holidays year 1:3	
2 3 0433	Holidays year 1:4	2	3 0434	Holidays year 1:5	
2 3 0435	Holidays year 1:6	2	3 0436	Holidays year 1:7	
2 3 0437	Holidays year 1:8	2	3 0438	Holidays year 1:9	
2 3 0439	Holidays year 1:10	2	3 0450	Holidays year 2:1	
2 3 0451	Holidays year 2:2	2	3 0452	Holidays year 2:3	
2 3 0453	Holidays year 2:4	2	3 0454	Holidays year 2:5	
2 3 0455	Holidays year 2:6	2	3 0456	Holidays year 2:7	
2 3 0457	Holidays year 2:8	2	3 0458	Holidays year 2:9	
2 3 0459	Holidays year 2:10	2	3 0470	Holidays year 3:1	
2 3 0471	Holidays year 3:2	2	3 0472	Holidays year 3:3	
2 3 0473	Holidays year 3:4	2	3 0474	Holidays year 3:5	
2 3 0475	Holidays year 3:6	2	3 0476	Holidays year 3:7	

CPKSoft Engineering

Industrial communication
drivers.

www.cpksoft.com

www.facebook.com/

cpksoftengineering

cpksoftengineering@

hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

2	3	0477	Holidays year 3:8	2	3	0478	Holidays year 3:9							
2	3	0479	Holidays year 3:10	2	3	0490	Holidays year 4:1							
2	3	0491	Holidays year 4:2	2	3	0492	Holidays year 4:3							
2	3	0493	Holidays year 4:4	2	3	0494	Holidays year 4:5							
2	3	0495	Holidays year 4:6	2	3	0496	Holidays year 4:7							
2	3	0497	Holidays year 4:8	2	3	0498	Holidays year 4:9							
2	3	0499	Holidays year 4:10	2	3	0510	Holidays year 5:1							
2	3	0511	Holidays year 5:2	2	3	0512	Holidays year 5:3							
2	3	0513	Holidays year 5:4	2	3	0514	Holidays year 5:5							
2	3	0515	Holidays year 5:6	2	3	0516	Holidays year 5:7							
2	3	0517	Holidays year 5:8	2	3	0518	Holidays year 5:9							
2	3	0519	Holidays year 5:10	2	3	0530	Holidays year 6:1							
2	3	0531	Holidays year 6:2	2	3	0532	Holidays year 6:3							
2	3	0533	Holidays year 6:4	2	3	0534	Holidays year 6:5							
2	3	0535	Holidays year 6:6	2	3	0536	Holidays year 6:7							
2	3	0537	Holidays year 6:8	2	3	0538	Holidays year 6:9							
2	3	0539	Holidays year 6:10	2	3	0608	Clear all seasons, present							
tariff	0	1	1 0609	Clear all daytypes, present tariff	0	1	1 0708							
Clear all seasons, comming	tariff	0	1	1 0709	Clear all daytypes, comming	tariff	0	1	1 0812	Remote				
0	1	1	0811	Remote control of relay 1	0	1	1	0812	Remote	0	1	1		
control of relay 2	0	1	1	0813	Remote control of relay 3	0	1	1	0814	Remote control of relay 4	0	1	1	
0814	Remote control of relay 4	0	1	1	0815	Remote control of relay 5	0	1	1	0816	Remote control of relay 6	0	1	1
0	1	1	0816	Remote control of relay 6	0	1	1	0820	Pulse length	0	1	2		
relay output	0	1	2	0821	Pulse length end MD-period	0	1	2						

Error messages

The following list shows the possible error messages that can be returned by the driver during a failed communication in the 'Status' property.

- [1005] DRIVER (Internal): Invalid driver stage
- [1101] DRIVER (Port): Error manipulating baud-rate for opto port communication
- [1102] DRIVER (Port): Error reading current baud-rate from port
- [1200] DRIVER (System): Error clearing stop date in %s
- [1201] DRIVER (System): Error closing %s
- [1202] DRIVER (System): Error creating %s
- [1203] DRIVER (System): Error obtaining factors and units information
- [1208] DRIVER (System): Error seeking end of %s
- [1210] DRIVER (System): Error writing to %s
- [1211] DRIVER (System): Invalid factor index
- [1300] PROTOCOL (Timeout): No answer
- [1413] PROTOCOL (Format): Invalid password
- [1433] PROTOCOL (Format): Validation error in device response
- [2002] CONFIG (DataType): Digital inputs are not supported by this driver
- [2003] CONFIG (DataType): Digital outputs are not supported by this driver
- [2136] CONFIG (NumValues): Maximum number of channels is 5
- [3042] CONFIG (P0): Invalid serial number
- [3508] CONFIG (P1): Invalid command
- [4092] CONFIG (P2): Invalid register id number
- [4500] CONFIG (P3): Format not supported
- [5006] CONFIG (P4): Invalid decimal digits size (0-4)
- [5017] CONFIG (P4): Invalid number
- [8131] CONFIG (Remote): Error restoring setting original baud-rate for Opto port

Supported devices

This driver can communicate with these devices, but is not necessarily limited to this list:

CEWE Instruments Prometer Meter

CPKSoft Engineering

Industrial communication
drivers.

www.cpksoft.com

www.facebook.com/

cpksoftengineering

cpksoftengineering@

hotmail.com

phone: 54-911-45788354

1990-2012