

Industrial communication solutions for Windows

XCVMITF Driver Manual

Circutor CVM-ITF/CVM-R8C Controllers Protocol Driver

Contents

XCVMITF technical specifications	3
General information.....	3
Command list	3
Read Voltages Phase-Phase INST (V).....	3
Read Voltages Phase-Phase MAX (V)	3
Read Voltages Phase-Phase MIN (V).....	3
Read Voltages Phase-Neutral INST (V).....	4
Read Voltages Phase-Neutral MAX (V).....	4
Read Voltages Phase-Neutral MIN (V).....	4
Read Currents INST (mA)	4
Read Currents MAX (mA).....	5
Read Currents MIN (mA).....	5
Read Active Powers INST (W)	5
Read Active Powers MAX (W).....	6
Read Active Powers MIN (W).....	6
Read Inductive Powers INST (var.L)	6
Read Inductive Powers MAX (var.L).....	6
Read Inductive Powers MIN (var.L).....	7
Read Capacitive Powers INST (var.C).....	7
Read Capacitive Powers MAX (var.C).....	7
Read Capacitive Powers MIN (var.C).....	8
Read Power Factors INST.....	8
Read Power Factors MAX.....	8
Read Power Factors MIN	8
Read Frequency INST (Hz)	9
Read Frequency MAX (Hz).....	9
Read Frequency MIN (Hz).....	9
Read Apparent Power INST (VA)	9
Read Apparent Power MAX (VA).....	10
Read Apparent Power MIN (VA).....	10
Read Transforming Ratios.....	10
Write Transforming Ratios.....	10
Read Type of Set Voltage	11

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/cpksoftengineering

cpksoftengineering@hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Write Measuring Mode (Type of Set Voltage)	11
Read Total Information	11
Read Active Energy (W.h)	12
Read Inductive Energy (varh.L)	12
Read Capacitive Energy (varh.C)	12
Read Initial Value of Positive Energies (W.h).....	13
Write Initial Positive Energies	13
Read Initial Value of Negative Energies (W.h)	13
Write Initial Negative Energies.....	13
Read Date and Time	14
Write Date and Time	14
Read Power Demand Period.....	14
Write Power Demand Period.....	15
Read Maximum Demand Value.....	15
Delete Maximum Demand Value	15
Read Input and Relay Status in CVM-R8C	15
Write Input and Relay Status in CVM-R8C	16
Read A/D Channels in CVM-R8C	16
Read Scale Factors of A/D Converter in CVM-R8C	16
Write Scale Factors of A/D Converter in CVM-R8C	16
Write Leds Activation in CVM-R8C	17
Read Integer Type Registers in CVM-R8C	17
Write Integer Type Registers in CVM-R8C	17
Error messages	17
Supported devices.....	18

CPKSoft Engineering

Industrial communication
drivers.

www.cpksoft.com

[www.facebook.com/
cpksoftengineering](https://www.facebook.com/cpksoftengineering)

[cpksoftengineering@
hotmail.com](mailto:cpksoftengineering@hotmail.com)

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

XCVMITF technical specifications

General information

XCVMITF driver allows you to connect with CIRCUTOR CVM-ITF/BD Series Supply Network Analyzer and CIRCUTOR CVM-R8C/R8D Programmable Peripherals. This driver complies with Instruction Manual M981 171/96-001 (2/2) from Circutor S.A.

Command list

Read Voltages Phase-Phase INST (V)

Description of this command:

Reads Voltages Phase-Phase INST in Volts.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-4

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

0

Values that are returned:

Value in PointValue (0) = Voltage Phase-Phase L12

Value in PointValue (1) = Voltage Phase-Phase L23

Value in PointValue (2) = Voltage Phase-Phase L31

Value in PointValue (3) = Voltage Phase-Phase Av

Read Voltages Phase-Phase MAX (V)

Description of this command:

Reads Voltages Phase-Phase MAX in Volts.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-3

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

1

Values that are returned:

Value in PointValue (0) = Voltage Phase-Phase L12 Max.

Value in PointValue (1) = Voltage Phase-Phase L23 Max.

Value in PointValue (2) = Voltage Phase-Phase L31 Max.

Read Voltages Phase-Phase MIN (V)

Description of this command:

Reads Voltages Phase-Phase MIN in Volts.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-3

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

2

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/cpksoftengineering

cpksoftengineering@hotmail.com

cpksoftengineering@hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Values that are returned:

Value in PointValue (0) = Voltage Phase-Phase L12 Min.
Value in PointValue (1) = Voltage Phase-Phase L23 Min.
Value in PointValue (2) = Voltage Phase-Phase L31 Min.

Read Voltages Phase-Neutral INST (V)

Description of this command:

Reads Voltages Phase-Neutral INST in Volts.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-4

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

3

Values that are returned:

Value in PointValue (0) = Voltage L1
Value in PointValue (1) = Voltage L2
Value in PointValue (2) = Voltage L3
Value in PointValue (3) = Voltage Av

Read Voltages Phase-Neutral MAX (V)

Description of this command:

Reads Voltages Phase-Neutral MAX in Volts.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-3

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

4

Values that are returned:

Value in PointValue (0) = Voltage L1 Max.
Value in PointValue (1) = Voltage L2 Max.
Value in PointValue (2) = Voltage L3 Max.

Read Voltages Phase-Neutral MIN (V)

Description of this command:

Reads Voltages Phase-Neutral MIN in Volts.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-3

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

5

Values that are returned:

Value in PointValue (0) = Voltage L1 Min.
Value in PointValue (1) = Voltage L2 Min.
Value in PointValue (2) = Voltage L3 Min.

Read Currents INST (mA)

Description of this command:

Reads Currents INST in mA.

Methods used to run this command:

Analog Input

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/cpksoftengineering

cpksoftengineering@hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Number of points accepted by this command:

1-4

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

6

Values that are returned:

Value in PointValue (0) = Current L1

Value in PointValue (1) = Current L2

Value in PointValue (2) = Current L3

Value in PointValue (3) = Current Av

Read Currents MAX (mA)

Description of this command:

Reads Currents MAX in mA.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-3

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

7

Values that are returned:

Value in PointValue (0) = Current L1 Max.

Value in PointValue (1) = Current L2 Max.

Value in PointValue (2) = Current L3 Max.

Read Currents MIN (mA)

Description of this command:

Reads Currents MIN in mA.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-3

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

8

Values that are returned:

Value in PointValue (0) = Current L1 Min.

Value in PointValue (1) = Current L2 Min.

Value in PointValue (2) = Current L3 Min.

Read Active Powers INST (W)

Description of this command:

Reads Active Powers INST in Watts.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-4

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

9

Values that are returned:

Value in PointValue (0) = Power L1

Value in PointValue (1) = Power L2

Value in PointValue (2) = Power L3

Value in PointValue (3) = Power III

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/cpksoftengineering

cpksoftengineering@hotmail.com

hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Read Active Powers MAX (W)

Description of this command:

Reads Active Powers MAX in Watts.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-4

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

10

Values that are returned:

Value in PointValue (0) = Power L1 Max.

Value in PointValue (1) = Power L2 Max.

Value in PointValue (2) = Power L3 Max.

Value in PointValue (3) = Power III Max.

Read Active Powers MIN (W)

Description of this command:

Reads Active Powers MIN in Watts.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-4

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

11

Values that are returned:

Value in PointValue (0) = Power L1 Min.

Value in PointValue (1) = Power L2 Min.

Value in PointValue (2) = Power L3 Min.

Value in PointValue (3) = Power III Min.

Read Inductive Powers INST (var.L)

Description of this command:

Reads Inductive Powers INST in var.L.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-4

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

12

Values that are returned:

Value in PointValue (0) = Inductive Power L1

Value in PointValue (1) = Inductive Power L2

Value in PointValue (2) = Inductive Power L3

Value in PointValue (3) = Inductive Power III

Read Inductive Powers MAX (var.L)

Description of this command:

Reads Inductive Powers MAX in var.L.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-4

Meaning of the DriverP0 parameter:

Unit Address (0-99).

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/cpksoftengineering

[cpksoftengineering@](mailto:cpksoftengineering@hotmail.com)

[hotmail.com](mailto:cpksoftengineering@hotmail.com)

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Meaning of the DriverP1 parameter:

13

Values that are returned:

Value in PointValue (0) = Inductive Power L1 Max.

Value in PointValue (1) = Inductive Power L2 Max.

Value in PointValue (2) = Inductive Power L3 Max.

Value in PointValue (3) = Inductive Power III Max.

Read Inductive Powers MIN (var.L)

Description of this command:

Reads Inductive Powers MIN in var.L.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-4

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

14

Values that are returned:

Value in PointValue (0) = Inductive Power L1 Min.

Value in PointValue (1) = Inductive Power L2 Min.

Value in PointValue (2) = Inductive Power L3 Min.

Value in PointValue (3) = Inductive Power III Min.

Read Capacitive Powers INST (var.C)

Description of this command:

Reads Capacitive Powers INST in var.C.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-4

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

15

Values that are returned:

Value in PointValue (0) = Capacitive Power L1

Value in PointValue (1) = Capacitive Power L2

Value in PointValue (2) = Capacitive Power L3

Value in PointValue (3) = Capacitive Power III

Read Capacitive Powers MAX (var.C)

Description of this command:

Reads Capacitive Powers MAX in var.C.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-4

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

16

Values that are returned:

Value in PointValue (0) = Capacitive Power L1 Max.

Value in PointValue (1) = Capacitive Power L2 Max.

Value in PointValue (2) = Capacitive Power L3 Max.

Value in PointValue (3) = Capacitive Power III Max.

CPKSoft Engineering

Industrial communication
drivers.

www.cpksoft.com

www.facebook.com/

cpksoftengineering

cpksoftengineering@

hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Read Capacitive Powers MIN (var.C)

Description of this command:

Reads Capacitive Powers MIN in var.C.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-3

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

17

Values that are returned:

Value in PointValue (0) = Capacitive Power L1 Min.

Value in PointValue (1) = Capacitive Power L2 Min.

Value in PointValue (2) = Capacitive Power L3 Min.

Read Power Factors INST

Description of this command:

Reads Power Factors INST.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-4

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

18

Values that are returned:

Value in PointValue (0) = Power Factor L1

Value in PointValue (1) = Power Factor L2

Value in PointValue (2) = Power Factor L3

Value in PointValue (3) = Power Factor Av

Read Power Factors MAX

Description of this command:

Reads Power Factors MAX.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-3

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

19

Values that are returned:

Value in PointValue (0) = Power Factor L1 Max.

Value in PointValue (1) = Power Factor L2 Max.

Value in PointValue (2) = Power Factor L3 Max.

Read Power Factors MIN

Description of this command:

Reads Power Factors MIN.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-3

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

20

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/cpksoftengineering

cpksoftengineering@hotmail.com

cpksoftengineering@hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Values that are returned:

Value in PointValue (0) = Power Factor L1 Min.
Value in PointValue (1) = Power Factor L2 Min.
Value in PointValue (2) = Power Factor L3 Min.

Read Frequency INST (Hz)

Description of this command:

Reads Frequency INST in Hz.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

21

Values that are returned:

Value in PointValue (0) = Frequency

Read Frequency MAX (Hz)

Description of this command:

Reads Frequency MAX in Hz.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

22

Values that are returned:

Value in PointValue (0) = Frequency Max.

Read Frequency MIN (Hz)

Description of this command:

Reads Frequency MIN in Hz.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

23

Values that are returned:

Value in PointValue (0) = Frequency Min.

Read Apparent Power INST (VA)

Description of this command:

Reads Apparent Power INST in VA.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

24

Values that are returned:

Value in PointValue (0) = Apparent Power.

CPKSoft Engineering

Industrial communication
drivers.

www.cpksoft.com

[www.facebook.com/
cpksoftengineering](https://www.facebook.com/cpksoftengineering)

[cpksoftengineering@
hotmail.com](mailto:cpksoftengineering@hotmail.com)

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Read Apparent Power MAX (VA)

Description of this command:

Reads Apparent Power MAX in VA.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

25

Values that are returned:

Value in PointValue (0) = Apparent Power Max.

Read Apparent Power MIN (VA)

Description of this command:

Reads Apparent Power MIN in VA.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

26

Values that are returned:

Value in PointValue (0) = Apparent Power Min.

Read Transforming Ratios

Description of this command:

Reads Transforming Ratios.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-3

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

27

Values that are returned:

Value in PointValue (0) = Prim V

Value in PointValue (1) = Sec V

Value in PointValue (2) = Prim A

Write Transforming Ratios

Description of this command:

Writes Transforming Ratios.

Methods used to run this command:

Analog Output

Number of points accepted by this command:

3

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

34

Values that are sent:

Value in PointValue (0) = Prim V

Value in PointValue (1) = Sec V

Value in PointValue (2) = Prim A

CPKSoft Engineering

Industrial communication
drivers.

www.cpksoft.com

[www.facebook.com/
cpksoftengineering](https://www.facebook.com/cpksoftengineering)

[cpksoftengineering@
hotmail.com](mailto:cpksoftengineering@hotmail.com)

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Read Type of Set Voltage

Description of this command:

Reads Type of Set Voltage.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

28

Values that are returned:

Value in PointValue (0) = Type of Set Voltage

Values that are sent:

- 0 = Phase - Phase (Compound)
- 1 = Phase - Neutral (Single)

Write Measuring Mode (Type of Set Voltage)

Description of this command:

Writes Measuring Mode (Type of Set Voltage).

Methods used to run this command:

Analog Output

Number of points accepted by this command:

1

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

35

Values that are sent:

Value in PointValue (0) = New Measuring Mode

- 0 = Phase - Phase (Compound)
- 1 = Phase - Neutral (Single)

Read Total Information

Description of this command:

Reads Total Information.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-30

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

29

Values that are returned:

- Value in PointValue (0) = Voltage Phase-Phase L12 (V).
- Value in PointValue (1) = Voltage Phase-Phase L23 (V).
- Value in PointValue (2) = Voltage Phase-Phase L31 (V).
- Value in PointValue (3) = Voltage Phase-Phase Av (V).
- Value in PointValue (4) = Voltage Phase-Neutral L1 (V).
- Value in PointValue (5) = Voltage Phase-Neutral L2 (V).
- Value in PointValue (6) = Voltage Phase-Neutral L3 (V).
- Value in PointValue (7) = Voltage Phase-Neutral Av.
- Value in PointValue (8) = Current L1 (mA).
- Value in PointValue (9) = Current L2 (mA).
- Value in PointValue (10) = Current L3 (mA).
- Value in PointValue (11) = Current Av (mA).
- Value in PointValue (12) = Active Power L1 (W).
- Value in PointValue (13) = Active Power L2 (W).
- Value in PointValue (14) = Active Power L3 (W).

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/cpksoftengineering

[cpksoftengineering@](mailto:cpksoftengineering@hotmail.com)

hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Value in PointValue (15) = Active Power III (W).
Value in PointValue (16) = Inductive Power L1 (var.L).
Value in PointValue (17) = Inductive Power L2 (var.L).
Value in PointValue (18) = Inductive Power L3 (var.L).
Value in PointValue (19) = Inductive Power III (var.L).
Value in PointValue (20) = Capacitive Power L1 (var.C).
Value in PointValue (21) = Capacitive Power L2 (var.C).
Value in PointValue (22) = Capacitive Power L3 (var.C).
Value in PointValue (23) = Capacitive Power III (var.C).
Value in PointValue (24) = Power Factor L1.
Value in PointValue (25) = Power Factor L2.
Value in PointValue (26) = Power Factor L3.
Value in PointValue (27) = Power Factor Av.
Value in PointValue (28) = Frequency.
Value in PointValue (29) = Apparent Power (VA).

Read Active Energy (W.h)

Description of this command:

Reads Active Energy in W.h.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

30

Values that are returned:

Value in PointValue (0) = Active Energy

Read Inductive Energy (varh.L)

Description of this command:

Reads Inductive Energy in varh.L.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

31

Values that are returned:

Value in PointValue (0) = Inductive Energy

Read Capacitive Energy (varh.C)

Description of this command:

Reads Capacitive Energy in varh.C.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

32

Values that are returned:

Value in PointValue (0) = Capacitive Energy

CPKSoft Engineering

Industrial communication
drivers.

www.cpksoft.com

[www.facebook.com/
cpksoftengineering](https://www.facebook.com/cpksoftengineering)

[cpksoftengineering@
hotmail.com](mailto:cpksoftengineering@hotmail.com)

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Read Initial Value of Positive Energies (W.h)

Description of this command:

Reads Initial Value of the Positive Energies.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-3

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

33

Values that are returned:

Value in PointValue (0) = Active Energy

Value in PointValue (1) = Inductive Energy

Value in PointValue (2) = Capacitive Energy

Write Initial Positive Energies

Description of this command:

Writes Initial value of the positive Energies.

Methods used to run this command:

Analog Output

Number of points accepted by this command:

3

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

36

Values that are sent:

Value in PointValue (0) = Active Energy

Value in PointValue (1) = Inductive Energy

Value in PointValue (2) = Capacitive Energy

Read Initial Value of Negative Energies (W.h)

Description of this command:

Reads Initial Value of the Negative Energies.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-3

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

45

Values that are returned:

Value in PointValue (0) = Active Energy

Value in PointValue (1) = Inductive Energy

Value in PointValue (2) = Capacitive Energy

Write Initial Negative Energies

Description of this command:

Writes Initial absolute value of the negative Energies.

Methods used to run this command:

Analog Output

Number of points accepted by this command:

3

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

46

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/cpksoftengineering

[cpksoftengineering@](mailto:cpksoftengineering@hotmail.com)

[hotmail.com](mailto:cpksoftengineering@hotmail.com)

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Values that are sent:

- Value in PointValue (0) = Active Energy (absolute value)
- Value in PointValue (1) = Inductive Energy (absolute value)
- Value in PointValue (2) = Capacitive Energy (absolute value)

Read Date and Time

Description of this command:

Reads Date and Time.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-6

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

47

Values that are returned:

- Value in PointValue (0) = Day (1-31)
- Value in PointValue (1) = Month (1-12)
- Value in PointValue (2) = Year (1990-2089)
- Value in PointValue (3) = Hour (0-23)
- Value in PointValue (4) = Minutes (0-59)
- Value in PointValue (5) = Seconds (0-59)

Write Date and Time

Description of this command:

Writes Date and Time.

Methods used to run this command:

Analog Output

Number of points accepted by this command:

6

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

48

Values that are sent:

- Value in PointValue (0) = Day (1-31)
- Value in PointValue (1) = Month (1-12)
- Value in PointValue (2) = Year (1990-2089)
- Value in PointValue (3) = Hour (0-23)
- Value in PointValue (4) = Minutes (0-59)
- Value in PointValue (5) = Seconds (0-59)

Read Power Demand Period

Description of this command:

Reads Power Demand Period + Parameter.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-2

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

49

Values that are returned:

- Value in PointValue (0) = Power Demand Period
- Value in PointValue (1) = Parameter
 - 21 = kW
 - 26 = KVA
 - 20 = AIII

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/cpksoftengineering

cpksoftengineering@hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Write Power Demand Period

Description of this command:

Writes Power Demand Period + Parameter.

Methods used to run this command:

Analog Output

Number of points accepted by this command:

2

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

50

Values that are sent:

Value in PointValue (0) = Power Demand Period

Value in PointValue (1) = Parameter

- 21 = kW

- 26 = KVA

- 20 = All

Read Maximum Demand Value

Description of this command:

Reads Maximum Demand Value.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-8

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

51

Values that are returned:

Value in PointValue (0) = Day (1-31)

Value in PointValue (1) = Month (1-12)

Value in PointValue (2) = Year (1990-2089)

Value in PointValue (3) = Hour (0-23)

Value in PointValue (4) = Minutes (0-59)

Value in PointValue (5) = Seconds (0-59)

Value in PointValue (6) = Maximum from the last reset

Value in PointValue (7) = Last Period maximum

Delete Maximum Demand Value

Description of this command:

Deletes Maximum Demand Value (max pd = 0).

Methods used to run this command:

Analog Output

Number of points accepted by this command:

1

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

52

Values that are sent:

Value in PointValue (0) = Not relevant.

Read Input and Relay Status in CVM-R8C

Description of this command:

Reads Input and Relay Status in CVM-R8C.

Methods used to run this command:

Digital Input

Number of points accepted by this command:

1-99

CPKSoft Engineering

Industrial communication
drivers.

www.cpksoft.com

www.facebook.com/

cpksoftengineering

cpksoftengineering@

hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

37

Meaning of the DriverP2 parameter:

Defines the first register to be read.

- 1 .. 18 = Inputs

- 100 .. 117 = External Relays

Write Input and Relay Status in CVM-R8C

Description of this command:

Writes Input and Relay Status in CVM-R8C.

Methods used to run this command:

Digital Output

Number of points accepted by this command:

1

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

38

Meaning of the DriverP2 parameter:

Defines the register to be written (0-9999).

Read A/D Channels in CVM-R8C

Description of this command:

Reads A/D Channels in CVM-R8C.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-2

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

39

Values that are sent:

Value in PointValue (0) = DC1 Channel.

Value in PointValue (1) = DC2 Channel.

Read Scale Factors of A/D Converter in CVM-R8C

Description of this command:

Reads Scale Factors of A/D Converter in CVM-R8C.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-2

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

40

Values that are sent:

Value in PointValue (0) = Channel Factor 1.

Value in PointValue (1) = Channel Factor 2.

Write Scale Factors of A/D Converter in CVM-R8C

Description of this command:

Writes Scale Factors of A/D Converter in CVM-R8C.

Methods used to run this command:

Analog Output

Number of points accepted by this command:

2

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/cpksoftengineering

cpksoftengineering@hotmail.com

cpksoftengineering@hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

41

Values that are sent:

Value in PointValue (0) = Channel Factor 1.

Value in PointValue (1) = Channel Factor 2.

Write Leds Activation in CVM-R8C

Description of this command:

Writes Leds Activation in CVM-R8C.

Methods used to run this command:

Digital Output

Number of points accepted by this command:

3

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

42

Values that are sent:

Value in PointValue (0) = Test (0 = Desactivate / 1 = Activate).

Value in PointValue (1) = Led 1 (Comm).

Value in PointValue (2) = Led 2 (CPU).

Read Integer Type Registers in CVM-R8C

Description of this command:

Reads Integer Type Registers in CVM-R8C.

Methods used to run this command:

Analog Input

Number of points accepted by this command:

1-99

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

43

Meaning of the DriverP2 parameter:

First register to be read (0-499).

Write Integer Type Registers in CVM-R8C

Description of this command:

Writes Integer Type Registers in CVM-R8C.

Methods used to run this command:

Analog Output

Number of points accepted by this command:

1

Meaning of the DriverP0 parameter:

Unit Address (0-99).

Meaning of the DriverP1 parameter:

44

Meaning of the DriverP2 parameter:

First register to be written (0-499).

Error messages

The following list shows the possible error messages that can be returned by the driver during a failed communication in the 'Status' property.

[1005] DRIVER (Internal): Invalid driver stage

[1300] PROTOCOL (Timeout): No answer

[1433] PROTOCOL (Format): Validation error in device response

CPKSoft Engineering

Industrial communication drivers.

www.cpksoft.com

www.facebook.com/

cpksoftengineering

cpksoftengineering@

hotmail.com

phone: 54-911-45788354

1990-2012

Industrial communication solutions for Windows

[2117] CONFIG (NumValues): Invalid number of values (must be 2)
[2122] CONFIG (NumValues): Invalid number of values (must be 3)
[2129] CONFIG (NumValues): Invalid number of values (must be 6)
[2147] CONFIG (NumValues): Only one value can be read or written
[2193] CONFIG (NumValues): Too many values (max=19)
[2194] CONFIG (NumValues): Too many values (max=2)
[2206] CONFIG (NumValues): Too many values (max=3)
[2207] CONFIG (NumValues): Too many values (max=30)
[2216] CONFIG (NumValues): Too many values (max=4)
[2226] CONFIG (NumValues): Too many values (max=6)
[2235] CONFIG (NumValues): Too many values (max=8)
[2243] CONFIG (NumValues): Too many values (max=99)
[3018] CONFIG (P0): Invalid device address (0-99)
[3508] CONFIG (P1): Invalid command
[4063] CONFIG (P2): Invalid first register (0-499)
[4064] CONFIG (P2): Invalid first register (0-999)
[4065] CONFIG (P2): Invalid first register (0-9999)
[8130] CONFIG (Remote): Error Response
[9500] CONFIG (Value): Invalid day in Value[0] (1-31)
[9501] CONFIG (Value): Invalid hour in Value[3] (0-23)
[9502] CONFIG (Value): Invalid minutes in Value[4] (0-59)
[9503] CONFIG (Value): Invalid month in Value[1] (1-12)
[9504] CONFIG (Value): Invalid parameter in Value[1] (20/21/26 only)
[9505] CONFIG (Value): Invalid seconds in Value[5] (0-59)
[9506] CONFIG (Value): Invalid year in Value[2] (1990-2089)

Supported devices

This driver can communicate with these devices, but is not necessarily limited to this list:

CIRCUTOR CVM-ITF Energy Network Analyzer
CIRCUTOR CVM-R8C Programmable Peripheral
CIRCUTOR CVM-R8D Programmable Peripheral
CIRCUTOR CVM-BD Series Supply Network Analyzer

CPKSoft Engineering

Industrial communication
drivers.

www.cpksoft.com

[www.facebook.com/
cpksoftengineering](https://www.facebook.com/cpksoftengineering)

[cpksoftengineering@
hotmail.com](mailto:cpksoftengineering@hotmail.com)

phone: 54-911-45788354

1990-2012